

# Minimotorkatalog

**Briggs & Stratton**

**Hatz**

**Honda**

**Iseki**

**John Deere**

**Kawasaki**

**Kohler**

**Kubota**

**Lombardini**

**Mitsubishi**

**Robin**


**Stihl**

**Yanmar m.m.**



**Lekang**  
Maskin AS

ACME	AS-MOTOREN	BRIGGS & STRATTON
<b>SA12366 Luftfilter</b> Erstatte 359A130/359130 H: 78 mm U: 113 mm I : 45 mm 	<b>1539 Luftfilter</b> H: 70 mm U: 64 mm I : 38 mm 	<b>SA10000 Luftfilter</b> Erstatte 270843 H: 38/9 mm U: 238/227 mm I : 114/98 mm 
<b>SA12832 Luftfilter</b> Erstatte 359121 H: 33 mm U: 188 mm I : 80 mm 	<b>20086 Luftfilter</b> Erstatte E07545 H: 66 mm U: 63 mm I : 36 mm 	<b>SA10001 Luftfilter</b> Erstatte 270987 H: 37/9 mm U: 142/125 mm I : 114/96 mm 
<b>SA12921 Luftfilter</b> Erstatte 359129 H: 41 mm U: 143 mm I : 64 mm 	<b>LX 279 Luftfilter</b> Erstatte 4221 H: 73 mm U: 70 mm I : 38 mm 	<b>SA10002 Luftfilter</b> Erstatte 270447 H: 37/6 mm U: 149/133 mm I : 105/89 mm 
<b>SN21563 Fuefilter</b> Erstatte 175102 H: 72 mm U: 37 mm I : 15/8 mm 	<b>SA11116 Luftfilter</b> Erstatte 2341-0030 H: 21 mm U: 180 mm I : 54 mm Forfilter er SA21116 	<b>SA12003 Luftfilter</b> Erstatte 272405 H: 27/7 mm U: 212/196 mm I : 73/56 mm 
<b>SN21564 Fuefilter</b> Erstatte 391012300 H: 69 mm U: 50 mm I : M 14x1.5/0 mm 	<b>SA12471 Luftfilter</b> Erstatte 2341-0028 H: 60 mm U: 129/61 mm I : 92/26 mm 	<b>SA12004 Luftfilter</b> Erstatte 270579 H: 36/7 mm U: 133/119 mm I : 87/73 mm 
<b>30228 Oliefilter</b> Erstatte 175005300 H: 65 mm U: 23 mm I : 10 mm/By-pass 	<b>SA12485 Luftfilter</b> Erstatte 23410026 H: 29 mm U: 145 mm I : 39 mm 	<b>SA10010 Luftfilter</b> Erstatte 270528 H: 40/7 mm U: 214/195 mm I : 110/94 mm 
AS-MOTOREN	BRIGGS & STRATTON	
<b>LX 253 Luftfilter</b> Erstatte 12576247-168-002 H: 68 mm U: 64 mm I : 38 mm 	<b>5571 Brændstofffilter</b> Erstatte 541037.2 H: 60 mm U: 19 mm I : 5 mm 	<b>SA10017 Luftfilter</b> Erstatte 270848 H: 36/10 mm U: 137/122 mm I : 100/83 mm 

BRIGGS & STRATTON		BRIGGS & STRATTON		BRIGGS & STRATTON	
<b>SA10051 Luftfilter</b> Erstatte 270251  H: 37/7 mm U: 148/131 mm l : 91/74 mm 	<b>SA11122 Forfilter</b> Erstatte 491435/271933  H: 10 mm U: 128 mm l : 107 mm  Forfilter for SA11120	<b>SA11129 Luftfilter</b> Erstatte 392286  H: 61 mm U: 126 mm l : 89 mm  Forfilter er SA22129			
<b>SA10058 Luftfilter</b> Erstatte 272235  H: 31/9 mm U: 150/135 mm l : 90/79 mm 	<b>SA11123 Luftfilter</b> Erstatte 491384  H: 35 mm U: 175 mm l : 87 mm  Forfilter er SA21123	<b>SA11130 Luftfilter</b> Erstatte 805113  H: 20 mm U: 180 mm l : 160 mm  Forfilter er SA11131			
<b>SA10067 Luftfilter</b> Erstatte 270067  H: 36/10 mm U: 143/125 mm l : 94/75 mm 	<b>SA11124 Luftfilter</b> Erstatte 491950  H: 70 mm U: 140/65 mm l : 100/25/8 mm  Forfilter er SA10068	<b>SA11131 Forfilter</b> Erstatte 805267  H: 7 mm U: 172 mm l : 150 mm  Forfilter for SA11130			
<b>SA10068 Forfilter</b> Erstatte 272218  H: 5 mm U: 160 mm l : 70 mm  Forfilter for SA11124	<b>SA11125 Luftfilter</b> Erstatte 491021  H: 77 mm U: 165/69 mm l : 123/25/9 mm  Forfilter er SA11126	<b>SA11132 Luftfilter</b> Erstatte 494511  H: 29 mm U: 175 mm l : 87 mm  Forfilter er SA21123			
<b>SA11118 Luftfilter</b> Erstatte 397795  H: 23 mm U: 162 mm l : 112 mm  Forfilter er SA12208	<b>SA11126 Forfilter</b> Erstatte 492947  H: 4 mm U: 160 mm l : 73 mm  Forfilter for SA11125	<b>SA11133 Luftfilter</b> Erstatte 496077  H: 33 mm U: 174 mm l : 86 mm  Forfilter er SA21123			
<b>SA11119 Luftfilter</b> Erstatte 399877  H: 22 mm U: 117 mm l : 117 mm 	<b>SA11127 Luftfilter</b> Erstatte 491519  H: 67 mm U: 215/67 mm l : 183/33/8 mm  Forfilter er SA11128	<b>SA11135 Luftfilter</b> Erstatte 399968  H: 64 mm U: 220/80 mm l : 186/43/(2X) 8 mm 			
<b>SA11120 Luftfilter</b> Erstatte 491588/399959  H: 22 mm U: 131 mm l : 112 mm  Forfilter er SA11122	<b>SA11128 Forfilter</b> Erstatte 271962  H: 6 mm U: 207 mm l : 66 mm  Forfilter for SA11127	<b>SA12016 Luftfilter</b> Erstatte 493910  H: 63 mm U: 183/66 mm l : 153/36/10 mm  Forfilter er SA22016			

BRIGGS & STRATTON		BRIGGS & STRATTON		BRIGGS & STRATTON	
<b>SA12017 Luftfilter</b> Erstatte 493909 H: 77 mm U: 183/65 mm l : 153/36/10 mm Forfilter er SA22017		<b>SA12175 Luftfilter</b> Erstatte 692446 H: 81/75 mm U: 102/61 mm l : 66/26 mm Forfilter er SA22727		<b>SA12308 Luftfilter</b> Erstatte 390492 H: 76 mm U: 97 mm l : 33 mm Forfilter er SA22405	
<b>SA12056 Luftfilter</b> Erstatte 270093 H: 80 mm U: 125 mm l : 33 mm		<b>SA12186 Luftfilter</b> Erstatte 691315 H: 28/10 mm U: 138/125 mm l : 118/106 mm		<b>SA12351 Luftfilter</b> Erstatte 692496 H: 75 mm U: 102/61 mm l : 66/26 mm Forfilter er SA22727	
<b>SA12074 Luftfilter</b> Erstatte 710265 H: 24 mm U: 160 mm l : 88 mm		<b>10057 Luftfilter</b> Erstatte 692519 H: 57 mm U: 197 mm l : 140 mm Forfilter er 14955		<b>SA12358 Luftfilter</b> Erstatte 697152 H: 38 mm U: 184 mm l : 79 mm	
<b>SA12076 Luftfilter</b> Erstatte 710266 H: 27 mm U: 211 mm l : 101 mm Forfilter er SA22076		<b>SA12205 Luftfilter</b> Erstatte 392308 H: 70 mm U: 71 mm l : 33 mm Forfilter er SA22205		<b>SA12424 Luftfilter</b> Erstatte 396424 H: 71 mm U: 71 mm l : 32/5 mm	
<b>SA12111 Luftfilter</b> Erstatte 497725 H: 80/75 mm U: 102/61 mm l : 66/26 mm		<b>SA12207 Luftfilter</b> Erstatte 494586 H: 56 mm U: 101/62 mm l : 64/25/8 mm Forfilter er SA22207		<b>SA12725 Luftfilter</b> Erstatte 393725 H: 65 mm U: 130/84 mm l : 103/58 mm	
<b>SA12140 Luftfilter</b> Erstatte 499486/695667 H: 38 mm U: 183 mm l : 148/108 mm		<b>SA12208 Forfilter</b> Erstatte 399039 H: 4 mm U: 152 mm l : 104 mm Forfilter for SA11118		<b>SA12726 Luftfilter</b> Erstatte 393406 H: 56 mm U: 134/78 mm l : 109/52 mm	
<b>AF25351 Luftfilter</b> Erstatte 541061-2 H: 173 mm U: 126 mm l : 65/9 mm		<b>SA12257 Luftfilter</b> Erstatte 613541/622942 H: 37 mm U: 225 mm l : 80 mm Forfilter er SA22257		<b>SA12727 Luftfilter</b> Erstatte 498596 H: 81/76 mm U: 102/61 mm l : 66/26 mm Forfilter er SA22727	

BRIGGS & STRATTON	BRIGGS & STRATTON	BRIGGS & STRATTON
<p><b>SA14524 Luftfilter</b> Erstatter 393959/390930</p>  <p>H: 94 mm U: 108 mm l : 51 mm</p> <p>Forfilter er SA24524</p>	<p><b>SA22140 Forfilter</b> Erstatter 273638</p>  <p>H: 6 mm U: 170 mm l : 90 mm</p>	<p><b>SA24524 Forfilter</b> Erstatter 270782</p>  <p>H: 5 mm U: 153 mm l : 98 mm</p> <p>Forfilter for SA14524</p>
<p><b>SA21123 Forfilter</b> Erstatter 492889</p>  <p>H: 9 mm U: 162/148 mm l : 74/58 mm</p> <p>Forfilter for SA11132/SA11123</p>	<p><b>14955 Forfilter</b> Erstatter 692520</p>  <p>H: 9 mm U: 297 mm l : 64 mm</p> <p>Forfilter for 10057</p>	<p><b>SA42359 Luftfilter</b> Erstatter 392642</p>  <p>H: 57 mm U: 176 mm l : 140 mm</p> <p>Forfilter er SA22359</p>
<p><b>SA22016 Forfilter</b> Erstatter 272477</p>  <p>H: 3 mm U: 170 mm l : 60 mm</p> <p>Forfilter for SA12016</p>	<p><b>SA22205 Forfilter</b> Erstatter 271466/270979</p>  <p>H: 9 mm U: 114 mm l : 77 mm</p> <p>Forfilter for SA12205</p>	<p><b>SA46176 Luftfilter</b> Erstatter 394019</p>  <p>H: 64 mm U: 246/87 mm l : 209/50 mm</p> <p>Forfilter er SA22359</p>
<p><b>SA22017 Forfilter</b> Erstatter 272403</p>  <p>H: 4 mm U: 170 mm l : 76 mm</p> <p>Forfilter for SA12017</p>	<p><b>SA22207 Forfilter</b> Erstatter 272533</p>  <p>H: 6 mm U: 122 mm l : 47 mm</p> <p>Forfilter for SA12207</p>	<p><b>FF 149 Fuelfilter</b> Erstatter 492836</p>  <p>H: 101 mm U: 49/44 mm l : 8/8 mm</p>
<p><b>SA22074 Forfilter</b> Erstatter 710267</p>  <p>H: 12 mm U: 145 mm l : 74 mm</p>	<p><b>SA22257 Forfilter</b> Erstatter 697015</p>  <p>H: 5 mm U: 160 mm l : 64 mm</p> <p>Forfilter for SA12257</p>	<p><b>SN20002 Fuelfilter</b> Erstatter 493629</p>  <p>H: 69 mm U: 35 mm l : 7/7 mm</p>
<p><b>SA22076 Forfilter</b> Erstatter 710268</p>  <p>H: 8 mm U: 192 mm l : 80 mm</p> <p>Forfilter for SA12076</p>	<p><b>SA22359 Forfilter</b> Erstatter 271271</p>  <p>H: 9 mm U: 263 mm l : 63 mm</p> <p>Forfilter for SA42359/SA46176/AF25340</p>	<p><b>SN20008 Fuelfilter</b> Erstatter 808116S</p>  <p>H: 41 mm U: 30 mm l : 14/7 mm</p>
<p><b>SA22129 Forfilter</b> Erstatter 270973</p>  <p>H: 8 mm U: 176 mm l : 65 mm</p> <p>Forfilter for SA11129</p>	<p><b>SA22727 Forfilter</b> Erstatter 273356</p>  <p>H: 4 mm U: 119 mm l : 68 mm</p> <p>Forfilter for SA12727/SA12175/SA12351</p>	<p><b>SN20104 Fuelfilter</b> Erstatter 394358 / 75 my</p>  <p>H: 45 mm U: 34 mm l : 7/7 mm</p>





















BRIGGS & STRATTON	EZ-GO	FARYMANN
<b>SN20105 Fuelfilter</b> Erstatter 298090 /125 my  H: 45 mm U: 34 mm I : 7/7 mm	<b>10046 Luftfilter</b> Erstatter 72144G01/72368G01  H: 41 mm U: 290 mm I : 128 mm	<b>SA 1990 Luftfilter</b> Erstatter 541065-2  H: 79 mm U: 131 mm I : 87 mm
<b>SN20106 Fuelfilter</b>  H: 52 mm U: 20 mm I : 6/6 mm	<b>15095 Luftfilter</b> Erstatter 26855G01/26635G01  H: 34 mm U: 218 mm I : 130 mm	<b>SA 5012 Luftfilter</b> Erstatter 541019-2  H: 156 mm U: 107/86 mm I : 31 mm
<b>LF 3826 Oliefilter</b> Erstatter 492932  H: 58 mm U: 76 mm I : 3/4-16 UNF By-pass	<b>FARYMANN</b> <b>AF 435KM Luftfilter</b>  H: 265 mm U: 131/103 mm I : 63/17 mm	<b>FF 167 Fuelfilter</b>  H: 72 mm U: 87 mm I : 19/17 mm
<b>LF 3335 Oliefilter</b> Erstatter 491056  H: 87 mm U: 76 mm I : 3/4-16 UNF By-pass	<b>SA12138 Luftfilter</b> Erstatter 541073-2  H: 116 mm U: 164 mm I : 88 mm	<b>LF 3402 Oliefilter</b>  H: 139 mm U: 98 mm I : 3/4 - 16 UNF
<b>LF 3338 Oliefilter</b> Erstatter 807894  H: 80 mm U: 82 mm I : 3/4-16 UNF By-pass	<b>AF25351 Luftfilter</b> Erstatter 541061-2  H: 173 mm U: 126 mm I : 65/9 mm	<b>LF 3778 Oliefilter</b>  H: 69 mm U: 95 mm I : 3/4 - 16 UNF
<b>31049 Oliefilter</b> Erstatter 499532/820314  H: 72 mm U: 65 mm I : 3/4-16 UNF	<b>AF25433 Luftfilter</b> Erstatter 541.052.2  H: 135 mm U: 105/97 mm I : 35 mm	<b>LF 3826 Oliefilter</b>  H: 59 mm U: 77/75 mm I : 3/4 - 16 UNF
<b>CLUB CAR</b> <b>SA 6042 Luftfilter</b> Erstatter 1015426  H: 43 mm U: 192 mm I : 153 mm	<b>SA13551 Luftfilter</b> Erstatter 541.053.2  H: 170 mm U: 104/97 mm I : 39 mm	<b>LF 3536 Oliefilter</b>  H: 102 mm U: 84/80 mm I : M 20 x 1.5

FLYMO		HATZ		HATZ	
<b>SA12001 Luftfilter</b> Erstatter 5146714/00/0  H: 155 mm U: 42 mm I : 12 mm		<b>SA12298 Luftfilter</b> Erstatter 01391800  H: 78 mm U: 113 mm I : 52 mm		<b>SN24632 Fuelfilter</b> Erstatter 50539200/05259300  H: 104 mm U: 59/49 mm I : 6.5 (x2)/5 mm	
<b>SA12184 Luftfilter</b>  H: 15 mm U: 106 mm I : 56 mm		<b>AF 4066 Luftfilter</b>  H: 225 mm U: 110 mm I : 50/9 mm		<b>FF 5135 Fuelfilter</b> Erstatter 50345700  H: 158 mm U: 81 mm I : M 16 x 1.5	
<b>SA22184 Luftfilter</b>  H: 4 mm U: 111 mm I : 63 mm		<b>AF25481 Luftfilter</b> Erstatter 04030100  H: 81 mm U: 141 mm I : 81 mm		<b>5541 Fuelfilter</b> Erstatter 50379100  H: 170 mm U: 92 mm I : 8 mm	
<b>HATZ</b>		<b>AF25376 Luftfilter</b> Erstatter 40084500/01493000  H: 95 mm U: 164 mm I : 87 mm		<b>FF 5018 Fuelfilter</b> Erstatter 40120300  H: 122 mm U: 81 mm I : M 16 x 1.5	
<b>AF25322 Luftfilter</b> Erstatter 00952900  H: 93 mm U: 244/161 mm I : 143/60 mm		<b>FF 146 Fuelfilter</b> Erstatter 4000730  H: 114 mm U: 65 mm I : 13 mm		<b>FF42002 Fuelfilter</b> Erstatter 50251500  H: 78 mm U: 77 mm I : M 16 x 1.5	
<b>10086 Luftfilter</b> Erstatter 50484100  H: 84/82 mm U: 142 mm I : 51/6 mm		<b>FF 147 Fuelfilter</b>  H: 145 mm U: 85 mm I : 14 mm		<b>50003 Fuelfilter</b> Erstatter 50440500  H: 56 mm U: 29 mm I : 8 mm	
<b>SA12211 Luftfilter</b> Erstatter 50426000  H: 78 mm U: 113 mm I : 52/6 mm		<b>P46/1 Fuelfilter</b> Erstatter 40043800  H: 133 mm U: 39 mm I : 9 mm		<b>LF 3402 Oliefilter</b> Erstatter 40065300  H: 139 mm U: 98 mm I : 3/4 - 16 UNF	

HATZ	HONDA	HONDA
<p><b>LF 3826 Oliefilter</b> Erstatter 50408400</p>  <p>H: 59 mm U: 77/75 mm I : 3/4 - 16 UNF</p>	<p><b>BE 4014 Fuelfilter</b> Erstatter 16900-ZE8-005/16900-ZE8-015</p>  <p>H: 65 mm U: 29/22 mm I : 7/5 mm</p>	<p><b>SA11219K Luftfilter</b> Erstatter 17210-ZC6-003/17220-ZC6-003</p>  <p>H: 205 mm U: 128/104 mm I : 63/18 mm</p>
<p><b>33378 Oliefilter</b> Erstatter 03795700</p>  <p>H: 64 mm U: 42 mm I : 14 mm By-Pass</p>	<p><b>BE 4018 Fuelfilter</b> Erstatter 16910-GB2-005</p>  <p>H: 52 mm U: 30 mm I : 5 mm</p>	<p><b>SA12000 Luftfilter</b> Erstatter 17210-ZE3-000</p>  <p>H: 92 mm U: 110/94 mm I : 42/38/6 mm</p> <p>Forfilter er SA22000</p>
<p><b>LF 3341 Oliefilter</b> Erstatter 401201000</p>  <p>H: 108 mm U: 97/95 mm I : 3/4 - 16 UNF</p>	<p><b>BE 4019 Fuelfilter</b> Erstatter 16910-ZV4-015</p>  <p>H: 68 mm U: 30 mm I : 7/6 mm</p>	<p><b>SA12002 Luftfilter</b> Erstatter 17210-734-003</p>  <p>H: 60 mm U: 119/64 mm I : 110/54/84/28/6 mm</p>
<p><b>H10W03 Oliefilter</b> Erstatter 40038140/40038100</p>  <p>H: 102 mm U: 98 mm I : 3/4 - 16 UNF</p>	<p><b>BE 4020 Fuelfilter</b> Erstatter 16910-ZG0-U02</p>  <p>H: 65 mm U: 30 mm I : 7/6 mm</p>	<p><b>SA12003 Luftfilter</b> Erstatter 17210-ZE5-000</p>  <p>H: 46 mm U: 183/58 mm I : 153/27/6 mm</p>
<p><b>H14W27 Oliefilter</b> Erstatter 505473</p>  <p>H: 138/124 mm U: 78 mm I : 3/4 - 16 UNF</p>	<p><b>BE 4021 Fuelfilter</b> Erstatter 17672-ZE2-W01</p>  <p>H: 42 mm U: 38/32 mm I : 28 mm</p>	<p><b>SA12010 Luftfilter</b> Erstatter 17211-ZG9-M00</p>  <p>H: 25 mm U: 145 mm I : 89 mm</p> <p>Forfilter er SA22010</p>
<p><b>LF 3605 Oliefilter</b></p>  <p>H: 134 mm U: 83 mm I : 25 mm</p>	<p><b>SA11120 Luftfilter</b> Erstatter 17211-ZL8-000</p>  <p>H: 22 mm U: 131 mm I : 112 mm</p>	<p><b>SA12073 Luftfilter</b> Erstatter 17205-GJ4-760</p>  <p>H: 15 mm U: 166 mm I : 84/8 mm</p>
<p><b>HONDA</b></p> <p><b>BE 4011 Fuelfilter</b> Erstatter 16955-ZE1-000</p>  <p>H: 53 mm U: 19/6 mm I:</p>	<p><b>SA11132 Luftfilter</b> Erstatter 17211-883-W20</p>  <p>H: 29 mm U: 175 mm I : 87 mm</p> <p>Forfilter er SA21123</p>	<p><b>SA12081 Luftfilter</b> Erstatter 17211-ZE7-W010</p>  <p>H: 49 mm U: 170/55 mm I : 143/26/16 mm</p>

HONDA		HONDA		HONDA	
<b>SA12082 Luftfilter</b> Erstatte 17211-ZG9-800  H: 24 mm U: 136 mm I : 60 mm Forfilter er SA22082	<b>SA12188 Luftfilter</b> Erstatte 17210-ZK7-V01  H: 158 mm U: 44 mm I : 19 mm Forfilter er SA22188	<b>SA12249 Luftfilter</b> Erstatte 17211-Z0A-003/17211-Z0A-000  H: 22 mm U: 219 mm I : 118 mm			
<b>SA12093 Luftfilter</b> Erstatte 17210-759-013  H: 205 mm U: 107/94 mm I : 46/10 mm	<b>SA12189 Luftfilter</b> Erstatte 17211-ZA8-800  H: 20 mm U: 116 mm I : 50 mm	<b>14954 Luftfilter</b> Erstatte 17211-896-700  H: 22 mm U: 97 mm I : 77 mm			
<b>SA12100 Luftfilter</b> Erstatte 17211-ZJ1-000  H: 39/29 mm U: 235 mm I : 202/180 mm Forfilter er SA22100	<b>SA12195 Luftfilter</b> Erstatte 17211-Z07-000  H: 17 mm U: 124 mm I : 82/60/10 mm	<b>SA12281 Luftfilter</b> Erstatte 17211-ZL8-A000/17211-ZS9-A01  H: 22 mm U: 132 mm I : 114 mm			
<b>SA12107 Luftfilter</b> Erstatte 17211-ZE7-W03  H: 54 mm U: 177/62 mm I : 142/27/7 mm Forfilter er SA22107	<b>SA12196 Luftfilter</b> Erstatte 17218-Z07-000  H: 25 mm U: 82 mm I : 25 mm	<b>SA12284 Luftfilter</b> Erstatte 17211-ZM3-800  H: 22 mm U: 76 mm I : 75 mm			
<b>SA12110 Luftfilter</b> Erstatte 17211-ZF5-V000  H: 87 mm U: 126/58 mm I : 92/25/8 mm Forfilter er SA22110	<b>SA12197 Luftfilter</b> Erstatte 17211-ZM7-000  H: 12 mm U: 88 mm I : 86 mm	<b>10068 Luftfilter</b> Erstatte 17210-ZJ1-841  H: 32 mm U: 228 mm I : 168 mm Forfilter er SA22300			
<b>SA12172 Luftfilter</b> Erstatte 17210-ZG3-003  H: 71 mm U: 122 mm I : 60/7 mm Forfilter er SA22172	<b>10045 Luftfilter</b> Erstatte 17211-ZM3-000  H: 20 mm U: 70 mm I : 55 mm	<b>SA12302 Luftfilter</b> Erstatte 17211-891-004  H: 60 mm U: 216/64 mm I : 185/38/2 x 9 mm Forfilter er SA22302			
<b>SA12179 Luftfilter</b> Erstatte 17211-899-000  H: 29 mm U: 164 mm I : 117 mm	<b>SA12248 Luftfilter</b> Erstatte 17211-ZB2-000  H: 31 mm U: 137 mm I : 79 mm	<b>SA12308 Luftfilter</b>  H: 76 mm U: 97 mm I : 33 mm Forfilter er SA22405			

HONDA		HONDA		HONDA	
<b>SA12342 Luftfilter</b> Erstatte 17211-ZL1-000 H: 25 mm U: 118 mm I : 75/66 mm 	<b>SA12406 Luftfilter</b> Erstatte 17210-ZE2-822/17210-ZE2-882 H: 78 mm U: 102/89 mm I : 41/38/6 mm  Forfilter er SA22406	<b>SA12834 Luftfilter</b> Erstatte 17211-ZB5-003 H: 62 mm U: 165/105 mm I : 38/11 (x2) mm  Forfilter er SA22834			
<b>SA12343 Luftfilter</b> Erstatte 17211-Z0H-000 H: 20 mm U: 104 mm I : 70 mm 	<b>SA12819 Luftfilter</b> Erstatte 17211-883-010 H: 38 mm U: 117 mm 	<b>SA12835 Luftfilter</b> Erstatte 17210-ZA0-505 H: 57 mm U: 180/128 mm I : 125/74 mm 			
<b>SA12348 Luftfilter</b> Erstatte 17211-ZG1-750 H: 25 mm U: 110 mm I : 102 mm 	<b>SA12820 Luftfilter</b> Erstatte 17211-ZE1-000 H: 40 mm U: 130 mm I : 100 mm 	<b>SA12998 Luftfilter</b> Erstatte 172A1-883-902 H: 65 mm U: 111/81 mm I : 55/8/6 mm 			
<b>SA12400 Luftfilter</b> Erstatte 17210-ZE6-003/17211-888-013 H: 48 mm U: 193/65 mm I : 152/27 mm  Forfilter er SA22400	<b>SA12821 Luftfilter</b> Erstatte 17210-ZE1-821/17210-ZE1-822 H: 68 mm U: 101/73 mm I : 34/32/5 mm  Forfilter er SA22821	<b>SA12999 Luftfilter</b> Erstatte 172A1-890-013/17211-890-023 H: 71 mm U: 135/97 mm I : 77/7 mm  Forfilter er SA22999			
<b>SA12401 Luftfilter</b> Erstatte 17211-ZG1-700 H: 25 mm U: 130 mm I : 70 mm 	<b>SA12822 Luftfilter</b> Erstatte 17210-ZE0-821/17210-ZE0-822 H: 52 mm U: 101/73 mm I : 34/32/5 mm  Forfilter er SA22822	<b>SA22000 Forfilter</b> Erstatte 17218-ZE3-000 H: 7 mm U: 140 mm I : 85 mm  Forfilter for SA12000			
<b>SA12402 Luftfilter</b> Erstatte 17211-896-000 H: 25 mm U: 95 mm I : 78 mm 	<b>SA12823 Luftfilter</b> Erstatte 17210-ZE7-003/17210-ZE7-013 H: 45 mm U: 190/63 mm I : 152/27/6 (x2) mm  Forfilter er SA22823	<b>SA22010 Forfilter</b> Erstatte 17218-ZG9-M00 H: 7 mm U: 135 mm I : 85 mm  Forfilter for SA12010			
<b>SA12405 Luftfilter</b> Erstatte 17210-ZE8-003 H: 81 mm U: 130/67 mm I : 90/28/6 mm  Forfilter er SA22405	<b>SA12831 Luftfilter</b> Erstatte 17211-ZA0-702 H: 44 mm U: 165/105 mm I : 109/49/6 (x2) mm  Forfilter er SA22831	<b>SA22013 Forfilter</b> Erstatte 17218-896-505 H: 5 mm U: 140 mm I : 33 mm 			

HONDA		HONDA		HONDA	
<b>SA22082 Forfilter</b> Erstatter 17218-ZG9-800  H: 6 mm U: 132 mm l : 53 mm Forfilter for SA12082	<b>14953 Forfilter</b> Erstatter 17218-ZJ1-840  H: 5 mm U: 220 mm l : 159 mm Forfilter for 10068	<b>SA22831 Forfilter</b>  H: 6 mm U: 182 mm l : 34 mm Forfilter for SA12831			
<b>SA22100 Forfilter</b> Erstatter 17218-ZJ1-000  H: 5 mm U: 216/131 mm l : 161/112 mm Forfilter for SA12100	<b>SA22302 Forfilter</b> Erstatter 17218-891-003  H: 6 mm U: 248 mm l : 55 mm Forfilter for SA12302	<b>SA22834 Forfilter</b>  H: 6 mm U: 190 mm l : 53 mm Forfilter for SA12834			
<b>SA22107 Forfilter</b>  H: 6 mm U: 175 mm l : 37 mm Forfilter for SA12107	<b>SA22400 Forfilter</b> Erstatter 17218-888-003  H: 6 mm U: 185 mm l : 36 mm Forfilter for SA12400	<b>SA22998 Forfilter</b> Erstatter 17218-883-901  H: 6 mm U: 125 mm l : 54 mm			
<b>SA22110 Forfilter</b>  H: 10 mm U: 147 mm l : 80 mm Forfilter for SA12110	<b>SA22405 Forfilter</b> Erstatter 17288-888-003  H: 6 mm U: 147 mm l : 72 mm Forfilter for SA12405/SA12308	<b>SA22999 Forfilter</b> Erstatter 17218-890-003/17211-889-003  H: 6 mm U: 150 mm l : 61 mm Forfilter for SA12999			
<b>SA22172 Forfilter</b>  H: 6 mm U: 163 mm l : 56 mm Forfilter for SA12172	<b>SA22406 Forfilter</b>  H: 6 mm U: 134 mm l : 68 mm Forfilter for SA12406	<b>SN25001 Fuelfilter</b> Erstatter 16910-ZG3-901  H: 99 mm U: 37/29 mm l : 7/7 mm			
<b>SA22188 Forfilter</b> Erstatter 17218-ZK7-V01  H: 8 mm U: 143 mm l : 73 mm Forfilter for SA12188	<b>SA22821 Forfilter</b>  H: 6 mm U: 107 mm l : 64 mm Forfilter for SA12821	<b>SN25002 Fuelfilter</b> Erstatter 17682-ZG3-003  H: 137 mm U: 51/37 mm l : 13 mm			
<b>SA22249 Forfilter</b> Erstatter 17218-Z0A-810  H: 6 mm U: 210 mm l : 45 mm	<b>SA22822 Forfilter</b>  H: 8 mm U: 120 mm l : 43 mm Forfilter for SA12822/SA12158	<b>SN25004 Fuelfilter</b> Erstatter 17682-ZG5-003  H: 96/89 mm U: 51/21 mm l : 10 mm			

HONDA		HUSQVARNA		HONDA	
<b>LF 3682 Oliefilter</b> Erstatte 80492-Y08-003 H: 130 mm U: 98/95 mm I : 3/4 - 16 UNF 	<b>BE 4031 Fuelfilter</b> H: 42/31 mm U: 20 mm I : 5 mm 	<b>SA12508 Luftfilter</b> Erstatte 5061457 H: 20 mm U: 133 mm I : 125 mm 			
<b>SO 6076 Oliefilter</b> Erstatte 15412-300-024/15410-426-000 H: 56 mm U: 76 mm I : 20 mm 	<b>SA12041 Luftfilter</b> Erstatte 5018071-01 H: 39 mm U: 95 mm I : 90 mm 	<b>ISEKI</b>		<b>1031 Luftfilter</b> Erstatte 1544-104-2020-0 H: 190 mm U: 125/83 mm I : 46/6 mm 	
<b>SO64300 Oliefilter</b> Erstatte 15221-ZG3-000 H: 59 mm U: 36/30 mm I : 8 mm 	<b>SA12185 Luftfilter</b> Erstatte 506263401 H: 53 mm U: 97/91 mm I : 56/51 mm 	<b>AF 4939 Luftfilter</b> Erstatte 1560-103-2024-0 H: 267 mm U: 146/104 mm I : 63/7 mm 			
<b>SO64304 Oliefilter</b> Erstatte 15220-ZG3-000 H: 69/59 mm U: 37/30 mm I : 8 mm 	<b>SA12314 Luftfilter</b> Erstatte 506269101 H: 20 mm U: 194 mm I : 125 mm 	<b>1052 Luftfilter</b> Erstatte 1550-104-2020-0 H: 250 mm U: 126/83 mm I : 46/6 mm 			
<b>LF 3536 Oliefilter</b> Erstatte 15400-PH1-014/15400-PH2-003 H: 102 mm U: 84/80 mm I : M 20 x 1.5 	<b>SA12365 Luftfilter</b> H: 36 mm U: 126 mm I : 115 mm 	<b>NA 267 Luftfilter</b> Erstatte 1444-101-3700-0 H: 244 mm U: 110/83 mm I : 46/10 mm 			
<b>33661 Oliefilter</b> Erstatte 15400-679-023 H: 82 mm U: 84/80 mm I : M 20 x 1.5 	<b>SA12500 Luftfilter</b> H: 59 mm U: 83/62 mm I : 57/35 mm 	<b>SA10025 Luftfilter</b> Erstatte 1572-103-2500-0 H: 265 mm U: 149/104 mm I : 63/14 mm 			
<b>HUSQVARNA</b>		<b>SA12507 Luftfilter</b> Erstatte 5061458 H: 79 mm U: 102 mm I : 60 mm 	<b>AF 1658 K Luftfilter</b> Erstatte 1427-101-2840-0 H: 185 mm U: 107/83 mm I : 44/12 mm 		
<b>BE 4016 Fuelfilter</b> Erstatte 503443201 H: 39 mm U: 21 mm I : 4 mm 					

ISEKI		ISEKI		ISUZU	
<b>SA12145 Luftfilter</b> Erstatter 5490-642-010-XX  H: 48 mm U: 102/83 mm I : 60 mm		<b>5819 Fuelfilter</b> Erstatter 1415-102-0110-0  H: 69 mm U: 35 mm I : 11/0		<b>LF 3490 Oliefilter</b> Erstatter 5-13240017-0/5-13240093-0  H: 117 mm U: 84/80 mm I : 3/4 - 16 UNF	
<b>SA12311 Luftfilter</b>  H: 80/68 mm U: 157/73 mm I : 120/36 mm  Forfilter er SA22311		<b>SN25000 Fuelfilter</b> Erstatter 6213-200-002-10  H: 112 mm U: 53/46 mm I : 8/7/7 mm		<b>33726 Oliefilter</b> Erstatter 8-94314263-2/8-94368727-0  H: 82 mm U: 72/68 mm I : M 20 x 1.5	
<b>AF 4991 Luftfilter</b>  H: 292 mm U: 180/135 mm I : 72/13 mm		<b>LF 3682 Oliefilter</b> Erstatter 1732-132-431  H: 130 mm U: 98/95 mm I : 3/4 - 16 UNF		<b>JACOBSEN</b>	
<b>SA13597 Luftfilter</b> Erstatter 3656-301-2130-0  H: 200 mm U: 149/104 mm I : 63/7 mm		<b>31049 Oliefilter</b> Erstatter 6213-240-0021-0  H: 62 mm U: 69/65 mm I : 3/4 - 16 UNF		<b>AF 1668 Luftfilter</b> Erstatter 230840/230848/236840  H: 40 mm U: 112/112 mm I : 76/76 mm	
<b>SA10793 Luftfilter</b> Erstatter 235116  H: 47 mm U: 154/154 mm I : 120/120 mm  Forfilter er SA20793		<b>SA22311 Forfilter</b> Erstatter 5110-132-1090-0  H: 6 mm U: 154 mm I : 64 mm  Forfilter for SA12311		<b>ISUZU</b>	
<b>SA22311 Forfilter</b> Erstatter 5110-132-1090-0  H: 6 mm U: 154 mm I : 64 mm  Forfilter for SA12311		<b>53017 Fuelfilter</b> Erstatter 8-94119532-0  H: 122 mm U: 84/80 mm I : M 20 x 1.5/M 22 x 1.5		<b>AF 257 Luftfilter</b> Erstatter 271272  H: 92 mm U: 238/238 mm I : 175/175 mm	
<b>FF 5103 Fuelfilter</b> Erstatter 1513-102-3290-0  H: 88 mm U: 50 mm I : 20/0 mm		<b>5852 Fuelfilter</b> Erstatter 5-87810197-0/1 / 1-87810049-0  H: 46 mm U: 42 mm I : 14 mm		<b>SA42359 Luftfilter</b> Erstatter 5000441  H: 56 mm U: 180/180 mm I : 138/138 mm	
<b>5844 Fuelfilter</b> Erstatter 5650-040-4879-0  H: 60 mm U: 29 mm I : 13/0 mm		<b>FF42003 Fuelfilter</b> Erstatter 8-94132947-1/8-94132947-0  H: 71 mm U: 78/76 mm I : M 20 x 1.5		<b>AF25538 Luftfilter</b> Erstatter 5000913/840352  H: 185 mm U: 90/90 mm I : 46/0 mm	

JACOBSEN		JACOBSEN		JACOBSEN	
<b>AF25575 Luftfilter</b> Erstatter 5000919  H: 270 mm U: 105/105 mm I : 62/0 mm		<b>FF 5135 Fuelfilter</b> Erstatter 5003212  H: 158 mm U: 77/77 mm I : M 16 x 1.5		<b>LF 3341 Oliefilter</b> Erstatter 555773  H: 107 mm U: 97/97 mm I : 3/4 - 16	
<b>AF25352 Luftfilter</b> Erstatter 5003370  H: 350 mm U: 165/165 mm I : 93/0 mm		<b>5554 Fuelfilter</b> Erstatter 556224/593391  H: 117 mm U: 54/54 mm I : 8/6 mm		<b>33691 Oliefilter</b> Erstatter 557759  H: 100 mm U: 80/80 mm I : M 20 x 1.5	
<b>AF 1658 K Luftfilter</b> Erstatter 502619  H: 184 mm U: 106/83 mm I : 45/10 mm		<b>LF 689 Oliefilter</b> Erstatter 130355  H: 108 mm U: 97/97 mm I : 3/4 - 16		<b>JOHN DEERE</b>	
<b>AF 435KM Luftfilter</b> Erstatter 549593/554700  H: 265 mm U: 131/104 mm I : 63/17 mm		<b>33661 Oliefilter</b> Erstatter 131044/550556/551044/554011  H: 80 mm U: 80/80 mm I : M 20 x 1.5		<b>52003 Fuelfilter</b> Erstatter AM116304  H: 108 mm U: 35 mm I : 8/6 mm	
<b>AF 437KM Luftfilter</b> Erstatter 549633/A819168  H: 289 mm U: 158/133 mm I : 69/17 mm		<b>33661 Oliefilter</b> Erstatter 131044/550556/551044/554011  H: 80 mm U: 80/80 mm I : M 20 x 1.5		<b>AF 435KM Luftfilter</b> Erstatter AH19847  H: 265 mm U: 131/103 mm I : 63/17 mm	
<b>AF 437KM Luftfilter</b> Erstatter 549633/A819168  H: 289 mm U: 158/133 mm I : 69/17 mm		<b>LF 3335 Oliefilter</b> Erstatter 2208174/5000440  H: 88 mm U: 77/77 mm I : 3/4 - 16		<b>AF 437KM Luftfilter</b> Erstatter AT18650T/AT20728  H: 280 mm U: 159/134 mm I : 66/17 mm	
<b>FF42003 Fuelfilter</b> Erstatter 2500809/557619  H: 88 mm U: 77/77 mm I : M 20 x 1.5		<b>LF 4016 Oliefilter</b> Erstatter 5003207  H: 116 mm U: 94/94 mm I : 3/4 - 16		<b>SA11117 Luftfilter</b> Erstatter M92359  H: 72 mm U: 116/95 mm I : 85/66/8 mm  Forfilter er SA21117	
<b>FF 5104 Fuelfilter</b> Erstatter 5001190/550463/ 550486/550489/840161  H: 87 mm U: 29/29 mm I : 13/0 mm		<b>LF 716 Oliefilter</b> Erstatter 554464  H: 116 mm U: 77/77 mm I : M 20 x 1.5		<b>SA11118 Luftfilter</b> Erstatter PT11025  H: 23 mm U: 162 mm I : 112 mm	

JOHN DEERE		JOHN DEERE		JOHN DEERE	
<b>SA11120 Luftfilter</b> Erstatte AM116236  H: 22 mm U: 131 mm I : 112 mm  	<b>SA12304 Luftfilter</b> Erstatte M70128  H: 81/70 mm U: 190/83 mm I : 155/47 mm  Forfilter er SA22304	<b>SA12360 Luftfilter</b> Erstatte AM134111  H: 29 mm U: 218 mm I : 69 mm  Forfilter er SA22360			
<b>AF 1658 K Luftfilter</b> Erstatte CH15451/M73009  H: 185 mm U: 107/83 mm I : 44/12 mm  	<b>SA12305 Luftfilter</b> Erstatte M70284  H: 72/60 mm U: 121/70 mm I : 85/34 mm  Forfilter er SA22305	<b>SA21117 Forfilter</b> Erstatte M92360  H: 6 mm U: 148 mm I : 73 mm  Forfilter for SA11117			
<b>AF 1669 Luftfilter</b> Erstatte HE1401228  H: 53 mm U: 204 mm I : 165 mm  	<b>SA12309 Luftfilter</b> Erstatte M79451  H: 54/50 mm U: 100/63 mm I : 68/30/13 mm  Forfilter for SA12304	<b>SA22304 Forfilter</b> Erstatte M70127  H: 5 mm U: 200 mm I : 60 mm  Forfilter for SA12304			
<b>SA12011 Luftfilter</b> Erstatte M73323  H: 64/51 mm U: 141/54 mm I : 111/22/22 mm  	<b>10062 Luftfilter</b> Erstatte M76077  H: 74/63 mm U: 222/89 mm I : 176/42 mm  Forfilter er SA22310	<b>SA22310 Forfilter</b> Erstatte M76076  H: 6 mm U: 230 mm I : 54 mm  Forfilter for SA12310			
<b>SA12120 Luftfilter</b> Erstatte M117254  H: 66 mm U: 192/112 mm I : 150/68 mm  	<b>SA12311 Luftfilter</b> Erstatte M97211  H: 80/68 mm U: 157/73 mm I : 120/36 mm  Forfilter er SA22311	<b>SA22322 Forfilter</b> Erstatte M71951  H: 8 mm U: 118 mm I : 48 mm  Forfilter for SA12322			
<b>SA12205 Luftfilter</b> Erstatte M83339  H: 70 mm U: 71 mm I : 33 mm  Forfilter er SA22205	<b>SA12322 Luftfilter</b> Erstatte 880701DY2  H: 53 mm U: 124 mm I : 109/75 mm  Forfilter er SA22322	<b>SA22360 Forfilter</b> Erstatte M151345  H: 10 mm U: 180 mm I : 60 mm  Forfilter for SA12360			
<b>AF25340 Luftfilter</b> Erstatte M47494  H: 63 mm U: 178 mm I : 137 mm  Forfilter er SA22359	<b>SA12324 Luftfilter</b> Erstatte M115978  H: 71/60 mm U: 169/90 mm I : 124/41 mm  Forfilter er SA22324	<b>SN20104 Fuelfilter</b> Erstatte AM38708 / 75 my  H: 45 mm U: 34 mm I : 7/7 mm  			

JOHN DEERE	JOHNSERED	KAWASAKI
<b>SN20105 Fuelfilter</b> Erstatte PT 4265 /125 my  H: 45 mm U: 34 mm I : 7/7 mm	<b>SA12990 Luftfilter</b> Erstatte 4357111  H: 93 mm U: 91 mm I : 55 mm  Yderfilter for SA12989	<b>SA12102 Luftfilter</b> Erstatte 11013-2128  H: 23 mm U: 129/116 mm I : 118 mm
<b>SN20106 Fuelfilter</b> Erstatte AM36483/ 75 my  H: 52 mm U: 20 mm I : 6/6 mm	<b>KAWASAKI</b> <b>SA12042 Luftfilter</b> Erstatte 11013-2086  H: 13 mm U: 72 mm	<b>SA12116 Luftfilter</b> Erstatte 49064-2066  H: 85/83 mm U: 118/67 mm I : 70/0 mm  Forfilter er SA22116
<b>59902 Fuelfilter</b> Erstatte M811032  H: 118 mm U: 53/20 mm I : 20/16 mm	<b>SA12043 Luftfilter</b> Erstatte 310401-1312A  H: 13 mm U: 72 mm	<b>SA12139 Luftfilter</b> Erstatte 11013-2074  H: 30 mm U: 127 mm I : 103 mm
<b>52008 Fuelfilter</b> Erstatte AL153517  H: 118/58 mm U: 50 mm I : 5/5 mm	<b>SA12044 Luftfilter</b> Erstatte 310301-1312A  H: 10 mm U: 47 mm	<b>SA12145 Luftfilter</b> Erstatte 49864-2010  H: 48 mm U: 102/83 mm I : 60/0 mm
<b>LF 3646 Oliefilter</b> Erstatte AM101378  H: 76 mm U: 84/80 mm I : M 20 x 1.5	<b>SA12045 Luftfilter</b> Erstatte 310101-1312A  H: 12 mm U: 53 mm	<b>SA12170 Luftfilter</b> Erstatte 11013-2151  H: 27 mm U: 206 mm I : 58 mm  Inkl. Forfilter uden forfilter brug SA12323
<b>JOHNSERED</b>		
<b>BE 4026 Fuelfilter</b> Erstatte 363400  H: 20 mm U: 20 mm I : 13 mm	<b>SA12088 Luftfilter</b> Erstatte 3155V1-212A  H: 57/47 mm U: 137/53 mm I : 104/21 mm	<b>SA12182 Luftfilter</b> Erstatte 11013-2152  H: 10 mm U: 165 mm I : 50 mm
<b>SA12989 Luftfilter</b> Erstatte 4357110  H: 80 mm U: 53/50 mm I : 30/5 mm  Inderfilter for SA12990	<b>SA12090 Luftfilter</b> Erstatte 14918-2311  H: 25 mm U: 117 mm I : 72 mm	<b>SA12191 Luftfilter</b> Erstatte 310370-1312A  H: 10 mm U: 68 mm I : 48 mm

KAWASAKI		KAWASAKI		KAWASAKI	
<b>SA12279 Luftfilter</b> Erstatte 11013-2154  H: 33 mm U: 129/115 mm I : 119 mm		<b>SA12317 Luftfilter</b> Erstatte 11013-1217/11029-1004  H: 115/97 mm U: 115/97 mm I : 73/0 mm		<b>SA12332 Luftfilter</b> Erstatte 49064-2015  H: 80/76 mm U: 76/48 mm I : 55/0 mm	
<b>SA12303 Luftfilter</b> Erstatte 11013-2021  H: 71/60 mm U: 178/57 mm I : 142/21 mm  Forfilter er 10028		<b>SA12321 Luftfilter</b> Erstatte 11013-2132  H: 60/55 mm U: 150/82 mm I : 98/20/0 mm		<b>SA12333 Luftfilter</b> Erstatte 49064-2064  H: 22 mm U: 185 mm I : 115 mm	
<b>SA12304 Luftfilter</b> Erstatte 11013-2098/11013-1214  H: 81/70 mm U: 190/83 mm I : 155/47 mm  Forfilter er SA22304		<b>SA12322 Luftfilter</b> Erstatte 31444AA-1312AA  H: 53 mm U: 124 mm I : 109/75 mm		<b>SA12335 Luftfilter</b> Erstatte 11013-2011  H: 32 mm U: 120 mm	
<b>SA12305 Luftfilter</b> Erstatte 11013-2093  H: 72/60 mm U: 121/70 mm I : 85/34 mm  Forfilter er SA22305		<b>SA12323 Luftfilter</b> Erstatte 11013-2151  H: 27 mm U: 206 mm I : 58 mm  Excl. Forfilter med forfilter brug SA12170		<b>SA12353 Luftfilter</b> Erstatte 11013-2065  H: 15 mm U: 105 mm	
<b>SA12309 Luftfilter</b> Erstatte 11029-2002  H: 54/50 mm U: 100/63 mm I : 68/30/13 mm  Forfilter er SA22309		<b>SA12324 Luftfilter</b> Erstatte 11013-2135  H: 71/60 mm U: 169/90 mm I : 124/41 mm  Forfilter er SA22324		<b>SA12354 Luftfilter</b> Erstatte 11013-2001  H: 10 mm U: 105 mm	
<b>SA12311 Luftfilter</b> Erstatte 11013-2110  H: 80/68 mm U: 157/73 mm I : 120/36 mm  Forfilter er SA22311		<b>SA12327 Luftfilter</b> Erstatte 11013-7002  H: 27 mm U: 210 mm I : 161/8 mm		<b>SA12355 Luftfilter</b> Erstatte 11013-7017  H: 27 mm U: 190 mm I : 112 mm  Forfilter er SA22355	
<b>SA12313 Luftfilter</b> Erstatte 11013-1263  H: 113/98 mm U: 76 mm I : 53/42 mm		<b>SA12331 Luftfilter</b> Erstatte 49064-2011  H: 62/57 mm U: 72/46 mm I : 49/0 mm		<b>SA12357 Luftfilter</b> Erstatte 11029-7015  H: 82 mm U: 190/90 mm I : 140/31 mm	

KAWASAKI		KAWASAKI		KOHLER	
<b>SA12360 Luftfilter</b> Erstatte 11029-7016/11029-7010  H: 29 mm U: 218 mm l : 69 mm    Forfilter er SA22360	<b>SA22322 Forfilter</b> Erstatte 11013-2010  H: 8 mm U: 118 mm l : 48 mm    Forfilter for SA12322	<b>AF 290 Luftfilter</b> Erstatte 271519/272042  H: 76 mm U: 160 mm l : 127 mm    Forfilter er SA20793			
<b>10028 Forfilter</b> Erstatte 11013-2020  H: 6 mm U: 182 mm l : 54 mm    Forfilter for SA12303	<b>SA22324 Forfilter</b> Erstatte 11013-2133  H: 5 mm U: 141 mm l : 56 mm    Forfilter for SA12324/SA12866	<b>SA10793 Luftfilter</b> Erstatte 235116  H: 51 mm U: 151 mm l : 118 mm    Forfilter er SA20793			
<b>SA22161 Forfilter</b> Erstatte 11013-2103  H: 7 mm U: 130 mm l : 80 mm    Forfilter for SA12116	<b>SA22355 Forfilter</b> Erstatte 11013-7016/11013-7034  H: 10 mm U: 182 mm l : 105 mm    Forfilter for SA12355	<b>SA11117 Luftfilter</b> Erstatte 1208305  H: 72 mm U: 116/95 mm l : 85/66/8 mm    Forfilter er SA21117			
<b>SA22304 Forfilter</b> Erstatte 11013-2097  H: 5 mm U: 200 mm l : 60 mm    Forfilter for SA12304	<b>SA22360 Forfilter</b> Erstatte 11013-7018  H: 10 mm U: 180 mm l : 60 mm    Forfilter for SA12360	<b>SA11134 Luftfilter</b> Erstatte 1208310/1208316  H: 82 mm U: 115/97 mm l : 85/83/6 mm    Forfilter er SA21134			
<b>SA22305 Forfilter</b> Erstatte 11013-2092  H: 5 mm U: 125 mm l : 56 mm    Forfilter for SA12305	<b>SN21602 Fuelfilter</b> Erstatte 49019-1055  H: 99 mm U: 37 mm l : 8/8 mm    Forfilter er SA21601	<b>AF 1651 Luftfilter</b> Erstatte 231847  H: 60 mm U: 111 mm l : 77 mm    Forfilter er SA21601			
<b>SA22309 Forfilter</b> Erstatte 11013-2119  H: 6 mm U: 114 mm l : 44 mm    Forfilter for SA12309	<div style="background-color: red; color: white; text-align: center; padding: 2px;"><b>KOHLER</b></div> <b>AF 250 Luftfilter</b> Erstatte 23575  H: 69 mm U: 76 mm l : 34 mm    Forfilter er SA21618	<b>AF 1668 Luftfilter</b> Erstatte 230840  H: 39 mm U: 112 mm l : 76 mm    Forfilter er SA21618			
<b>SA22311 Forfilter</b> Erstatte 11013-2109  H: 6 mm U: 154 mm l : 64 mm    Forfilter for SA12311	<b>AF 257 Luftfilter</b> Erstatte 271276  H: 94 mm U: 230 mm l : 175 mm    Forfilter er SA21922	<b>AF 1972 Luftfilter</b> Erstatte 277138  H: 104 mm U: 151 mm l : 117 mm    Forfilter er SA21922			

KOHLER		KOHLER		KOHLER	
<b>SA11932 Luftfilter</b> Erstatte 4508302  H: 76 mm U: 152 mm I : 118 mm  Forfilter er SA21932		<b>AF 4539 Luftfilter</b> Erstatte 253108  H: 278 mm U: 205 mm I : 136 mm		<b>SA21932 Forfilter</b> Erstatte 4508301  H: 6 mm U: 235 mm I : 80 mm  Forfilter for SA11932	
<b>SA12137 Luftfilter</b> Erstatte 2408303  H: 74 mm U: 177 mm I : 142 mm  Forfilter er SA22137		<b>SA20793 Forfilter</b>  H: 6 mm U: 215 mm I : 45 mm  Forfilter for SA10793		<b>SA22137 Forfilter</b> Erstatte 2408305  H: 5 mm U: 253 mm I : 74 mm  Forfilter for SA12137	
<b>AF25340 Luftfilter</b> Erstatte 4708303  H: 63 mm U: 178 mm I : 137 mm  Forfilter er SA22359		<b>SA21117 Forfilter</b> Erstatte 1208308  H: 6 mm U: 148 mm I : 73 mm  Forfilter for SA11117		<b>SA22359 Forfilter</b> Erstatte 2408302  H: 9 mm U: 263 mm I : 63 mm  Forfilter for SA42359/AF25340	
<b>SA12218 Forfilter</b> Erstatte 1508305  H: 6 mm U: 79 mm I : 79 mm  Forfilter for SA12220		<b>SA21134 Forfilter</b> Erstatte 1208312  H: 6 mm U: 150 mm I : 85 mm  Forfilter for SA11134		<b>SA24528 Forfilter</b> Erstatte 5208301  H: 6 mm U: 248 mm I : 44 mm  Forfilter for SA14528	
<b>SA12220 Luftfilter</b> Erstatte 1508301  H: 23 mm U: 100 mm I : 100 mm  Forfilter er SA12218		<b>SA21601 Forfilter</b> Erstatte 234869  H: 6 mm U: 163 mm I : 57 mm  Forfilter for SA11601		<b>SA42359 Luftfilter</b>  H: 57 mm U: 176 mm I : 140 mm  Forfilter er SA22359	
<b>SA12246 Luftfilter</b> Erstatte 2808304 S  H: 107 mm U: 116 mm I : 78 mm		<b>SA21618 Forfilter</b> Erstatte 234870  H: 6 mm U: 163 mm I : 34 mm  Forfilter for SA11618		<b>LF 3568 Oliefilter</b> Erstatte 277233  H: 177 mm U: 79/76 mm I : 3/4 - 16 UNF  	
<b>SA14528 Luftfilter</b> Erstatte 4708301  H: 46 mm U: 176 mm I : 142 mm  Forfilter er SA24528		<b>SA21922 Forfilter</b> Erstatte 277593  H: 6 mm U: 216 mm I : 97 mm  Forfilter for SA11922		<b>KUBOTA</b>	
				<b>AF 437KM Luftfilter</b> Erstatte 15000-3710-1  H: 280 mm U: 159/134 mm I : 66/17 mm  	

KUBOTA		KUBOTA		KUBOTA	
<b>SA12318 Luftfilter</b> Erstatte 15261-1122-0  H: 200 mm U: 155 mm I : 87/18		<b>SA12099 Luftfilter</b> Erstatte 12812-1121-0  H: 35/30 mm U: 109 mm I : 100 mm		<b>SA12172 Luftfilter</b> Erstatte 10460-1118-0  H: 71 mm U: 122 mm I : 60/7 mm	
<b>SA12007 Luftfilter</b> Erstatte 15621-1118-0  H: 170 mm U: 85 mm I : 55/18 mm		<b>SA12101 Luftfilter</b> Erstatte 16667-1108-0  H: 49/33 mm U: 180 mm I : 106 mm		<b>SA12301 Luftfilter</b>   H: 43/40 mm U: 107 mm I : 94 mm	
<b>SA12012 Luftfilter</b> Erstatte 13134-1118-0  H: 81/75 mm U: 76/48 mm I : 55/0 mm		<b>AF25440 K Luftfilter</b> Erstatte 14791-1118-0  H: 109 mm U: 104/87 mm I : 25/31 mm		<b>SA12301 Luftfilter</b> Erstatte 12867-1121-2  H: 43 mm U: 105 mm I : 95 mm	
<b>SA12013 Luftfilter</b> Erstatte 12101-1121-0  H: 44 mm U: 141/53 mm I : 110/22/22 mm		<b>SA12159 Luftfilter</b> Erstatte 14348-1118-0  H: 107 mm U: 119/102 mm I : 40/11 mm		<b>AF 4991 Luftfilter</b> Erstatte 17351-1108-0/17351-1108-3  H: 292 mm U: 180/135 mm I : 72/13 mm	
<b>SA12018 Luftfilter</b> Erstatte 12182-1108-0  H: 67 mm U: 122/114 mm I : 58/6 mm		<b>SA12163 Luftfilter</b> Erstatte 13892-1108-0  H: 71 mm U: 106/89 mm I : 40/0 mm  Forfilter er SA22163		<b>SA12824 Luftfilter</b> Erstatte 12681-1122-0  H: 55/44 mm U: 200/52 mm I : 168/20 mm  Forfilter er SA22824	
<b>10011 Luftfilter</b> Erstatte 11460-1118-0  H: 73 mm U: 125/122 mm I : 60/6 mm		<b>SA12164 Luftfilter</b> Erstatte 12451-1108-0  H: 74 mm U: 106/89 mm I : 40/7 mm  Forfilter er SA22163		<b>SA12825 Luftfilter</b> Erstatte 12191-1122-0  H: 65/58 mm U: 140/53 mm I : 111/22 mm	
<b>SA12098 Luftfilter</b> Erstatte 12545-1108-0  H: 54/45 mm U: 130 mm I : 111 mm		<b>SA12165 Luftfilter</b> Erstatte 12314-1121-0/12314-1221-0  H: 49 mm U: 141/53 mm I : 110/22 mm  Forfilter er SA22165		<b>SA12866 Luftfilter</b> Erstatte 13907-1121-0  H: 58 mm U: 89 mm I : 67 mm  Forfilter er SA22324	

KUBOTA		KUBOTA		KUBOTA	
<b>AF25221 Luftfilter</b> Erstatter 11420-1118-0  H: 50 mm U: 123/112 mm I : 64/49 mm		<b>AF25373 K Luftfilter</b> Erstatter 15451-1108-0  H: 160 mm U: 198/154 mm I : 88/17 mm		<b>FF 5468 Fuelfilter</b> Erstatter 15291-4301-2  H: 69 mm U: 35 mm I : 13/12/0 mm	
<b>AF 4066 Luftfilter</b>  H: 225 mm U: 110 mm I : 50/9 mm		<b>FF 5018 Fuelfilter</b>  H: 122 mm U: 81 mm I : M 16 x 1.5		<b>5819 Fuelfilter</b> Erstatter 10450-055710  H: 69 mm U: 35 mm I : 13/12/0 mm	
<b>AF 4502K Luftfilter</b> Erstatter 15852-1101-1/15852-1108-0  H: 188/174 mm U: 124/107 mm I : 44/12 mm		<b>SN20001 Fuelfilter</b> Erstatter 11420-4301-0  H: 117 mm U: 57/32 mm I : 6 mm		<b>FF 5104 Fuelfilter</b> Erstatter 15231-4356-3  H: 87 mm U: 29 mm I : 13/0 mm	
<b>AF 4760 Luftfilter</b> Erstatter 15287-1149-0  H: 232 mm U: 63/61 mm I : 49/17 mm		<b>SN20003 Fuelfilter</b> Erstatter 11460-4301-2  H: 141 mm U: 57/32 mm I : 6 mm		<b>5827 Fuelfilter</b> Erstatter 16271-4356-0  H: 90 mm U: 35 mm I : 13/12/0 mm	
<b>1279 Luftfilter</b> Erstatter 6A100-8263-0  H: 177 mm U: 90 mm I : 42/0 mm		<b>50023 Fuelfilter</b> Erstatter RA211-51280  H: 81 mm U: 50 mm I : 20/0 mm		<b>SN21599 Fuelfilter</b> Erstatter 6A320-5993-0  H: 53 mm U: 45/35 mm I : 6/0 mm	
<b>SA22163 Forfilter</b>  H: 9 mm U: 143 mm I : 67 mm  Forfilter for SA12163/SA12164		<b>FF 5103 Fuelfilter</b> Erstatter 15521-4316-0  H: 88 mm U: 50 mm I : 20/0 mm		<b>5541 Fuelfilter</b> Erstatter RG108-2341-0  H: 170 mm U: 92 mm I : 8 mm	
<b>SA22824 Forfilter</b>  H: 6 mm U: 202 mm I : 36 mm  Forfilter for SA12824		<b>5856 Fuelfilter</b> Erstatter RB101-5128-0  H: 50 mm U: 35 mm I : 13/12/0 mm		<b>FF42002 Fuelfilter</b>  H: 78 mm U: 77 mm I : M 16 x 1.5	

KUBOTA	LOMBARDINI	LOMBARDINI
<p><b>LF 3341 Oliefilter</b> Erstatter 15521-3243-1</p> <p>H: 108 mm U: 97/95 mm I : 3/4 - 16 UNF</p> 	<p><b>SA12315 Luftfilter</b> Erstatter 2175.239</p> <p>H: 72/65 mm U: 125 mm I : 65/10 mm</p> <p>Forfilter er SA22304</p> 	<p><b>SA17096 Luftfilter</b> Erstatter 550-2175-096/2175-134</p> <p>H: 38 mm U: 160 mm I : 157 mm</p> 
<p><b>LF 3682 Oliefilter</b> Erstatter 1C010-3243-0/1C020-3243-0</p> <p>H: 130 mm U: 98/95 mm I : 3/4 - 16 UNF</p> 	<p><b>10108 Luftfilter</b> Erstatter 2175.215/2175.223</p> <p>H: 80 mm U: 118 mm I : 63/6 mm</p> 	<p><b>1023 Luftfilter</b> Erstatter 2175-105/2175-132</p> <p>H: 40 mm U: 223 mm I : 135 mm</p> 
<p><b>33727 Oliefilter</b> Erstatter 15853-9917-0</p> <p>H: 66 mm U: 68/65 mm I : M 20 x 1.5</p> 	<p><b>SA12921 Luftfilter</b> Erstatter 2175.097</p> <p>H: 41 mm U: 143 mm I : 64 mm</p> 	<p><b>1174 Luftfilter</b> Erstatter 2175-128</p> <p>H: 76 mm U: 104 mm I : 63/7 mm</p> 
<p><b>LF 3646 Oliefilter</b> Erstatter 15241-3209-0/76611-3671-0</p> <p>H: 76 mm U: 84/80 mm I : M 20 x 1.5</p> 	<p><b>SA12922 Luftfilter</b> Erstatter 2175.150</p> <p>H: 29 mm U: 153 mm I : 104 mm</p> 	<p><b>SA17128 Luftfilter</b> Erstatter 2175-168</p> <p>H: 63 mm U: 108/104 mm I : 64/7 mm</p> 
<p><b>LF 3313 Oliefilter</b> Erstatter 15831-3243-0</p> <p>H: 131 mm U: 97 mm I : 3/4 - 16 UNF</p> 	<p><b>AF 4085 Luftfilter</b> Erstatter 530.2175.050</p> <p>H: 75 mm U: 140 mm I : 96 mm</p> 	<p><b>SA22304 Forfilter</b></p> <p>H: 5 mm U: 200 mm I : 60 mm</p> <p>Forfilter for SA12315</p> 
<p><b>LF 3536 Oliefilter</b> Erstatter 16271-3209-0</p> <p>H: 102 mm U: 84/80 mm I : M 20 x 1.5</p> 	<p><b>AF 4066 Luftfilter</b></p> <p>H: 225 mm U: 110 mm I : 50/9 mm</p> 	<p><b>SA 7000 Luftfilter</b> Erstatter 515.2175.073</p> <p>H: 207 mm U: 90 mm I : 50 mm</p> 
<p><b>LOMBARDINI</b></p> <p><b>SA12199 Luftfilter</b> Erstatter 549.6062</p> <p>H: 30 mm U: 142 mm I : 94 mm</p> 	<p><b>SA17017 Luftfilter</b> Erstatter 560.2175.048</p> <p>H: 69 mm U: 163/150 mm I : 91 mm</p> 	<p><b>SA 7005 Luftfilter</b> Erstatter 2175-119</p> <p>H: 40 mm U: 275 mm I : 133 mm</p> 

LOMBARDINI		LOMBARDINI		LOMBARDINI	
<b>SA 7028 Luftfilter</b> Erstatter 292.5496.110  H: 35 mm U: 138 mm I : 43 mm		<b>5557 Fuelfilter</b> Erstatter 196.3730.096  H: 86 mm U: 48/43 mm I : 6 (x3) mm		<b>LF 716 Oliefilter</b> Erstatter 104.2175.104  H: 122 mm U: 78/77 mm I : M 20 x 1.5 By-pass	
<b>FF 5018 Fuelfilter</b> Erstatter 104.3740.068  H: 122 mm U: 81 mm I : M 16 x 1.5		<b>SN80029 Fuelfilter</b> Erstatter 39144  H: 87 mm U: 54/48 mm I : 7/7/6 mm		<b>SO 8005 Oliefilter</b> Erstatter 400.2175.086  H: 108 mm U: 54 mm I : 14 mm	
<b>FF 146 Fuelfilter</b> Erstatter 276.2175.14/276.2175.24  H: 114 mm U: 65 mm I : 13 mm		<b>FF 5280 Fuelfilter</b> Erstatter 500-2175-32  H: 52 mm U: 42 mm I : 14/9 mm		<b>33379 Oliefilter</b> Erstatter 2175.129  H: 90 mm U: 26/18 mm I : 6 mm/By-pass	
<b>FF 147 Fuelfilter</b>   H: 145 mm U: 85 mm I : 14 mm		<b>FF 5281 Fuelfilter</b> Erstatter 273-2175-09  H: 51 mm U: 50 mm I : 14/10 mm		<b>30205 Oliefilter</b> Erstatter 2175-171  H: 82 mm U: 19/13 mm I : 6/0 mm	
<b>SN 296 Fuelfilter</b> Erstatter 2175.043  H: 80 mm U: 63 mm I : 16/13 mm		<b>LF 655 Oliefilter</b> Erstatter 2175.036/2175.071  H: 120 mm U: 80 mm I : 3/4 - 16 UNF		<b>SO 8035 Oliefilter</b> Erstatter 276.2175.11  H: 82 mm U: 70 mm I : 14 mm	
<b>SN 535 Fuelfilter</b> Erstatter 515.2175.186/515.2175.66  H: 117 mm U: 51/48 mm I : M 12 x 1.75		<b>LF 3678 Oliefilter</b> Erstatter 270.2175.28  H: 73 mm U: 79/76 mm I : M 14 x 1.5 By-pass		<b>LF 3624 Oliefilter</b> Erstatter 2175.131/2175.137  H: 92 mm U: 79/76 mm I : M 20 x 1.5/By-pass	
<b>FF42002 Fuelfilter</b> Erstatter 115.2175.138/2175.083  H: 78 mm U: 77 mm I : M 16 x 1.5		<b>31002 Oliefilter</b> Erstatter 2175.072  H: 117 mm U: 51 mm I : M 14 x 1.5		<b>30235 Oliefilter</b> Erstatter 277.2175.12  H: 248 mm U: 69 mm I : 30/15 mm	

LOMBARDINI		MAKITA		MITSUBISHI	
<b>SO 8421 Oliefilter</b>  H: 57 mm U: 51 mm I : 18/0 mm	<b>SA12252 Luftfilter</b> Erstatter 541-30440-20  H: 21 mm U: 55 mm I : 55/39 mm	<b>AF 1651 Luftfilter</b> Erstatter mm510090  H: 62 mm U: 117 mm I : 72 mm			
<b>3072 Oliefilter</b> Erstatter 500-2175-19  H: 52 mm U: 23 mm I : 10 mm/By-pass	<b>SA12253 Luftfilter</b> Erstatter 541-35071-01  H: 15 mm U: 92 mm I : 83 mm	<b>AF 1658 k Luftfilter</b> Erstatter MD200570  H: 185 mm U: 107/83 mm I : 44/12 mm			
<b>3035 Oliefilter</b> Erstatter 560-2175-044  H: 76 mm U: 23 mm I : 10 mm/By-pass	<b>10017 Forfilter</b> Erstatter 394-17303-0  H: 20 mm U: 138 mm I : 92/26 mm  Forfilter for SA12126	<b>SA12070 Luftfilter</b> Erstatter KA40029AA  H: 25 mm U: 91 mm I : 67/36 mm			
<b>30037 Oliefilter</b> Erstatter 710-2175-25  H: 65 mm U: 38 mm I : 12 mm/By-pass	<b>MITSUBISHI</b>		<b>SA12094 Luftfilter</b> Erstatter mm510093 /mm510094  H: 98 mm U: 136/114 mm I : 42 mm		
<b>MAKITA</b>		<b>FT24V Fuelfilter</b> Erstatter mm335368  H: 108/90 mm U: 52/46 mm I : 9/7 mm	<b>SA12130 Luftfilter</b> Erstatter FA24092  H: 44 mm U: 139 mm I : 88 mm		
<b>SA11110 Luftfilter</b> Erstatter 001173020/001173030  H: 76/69 mm U: 59/53 mm I : 52/8 Inderfilter for AF4525	<b>52004 Fuelfilter</b> Erstatter mm435191  H: 98 mm U: 55/46 mm I : 8/7 mm	<b>SA12131 Luftfilter</b> Erstatter FA25269  H: 24 mm U: 122 mm I : 79 mm			
<b>AF 4525 Luftfilter</b>  H: 71 mm U: 98 mm I : 60 mm  Yderfilter for SA11110	<b>SA12126 Luftfilter</b> Erstatter 394-17301-0  H: 58 mm U: 107 mm I : 82 mm  Forfilter er 10017	<b>53017 Fuelfilter</b> Erstatter MB433425  H: 122 mm U: 84/80 mm I : M 20 x 1.5/M 22 x 1.5	<b>SA12133 Luftfilter</b> Erstatter KA40026AA  H: 35 mm U: 90 mm I : 66/35 mm		

MITSUBISHI		MITSUBISHI		PARTNER	
<b>SA12134 Luftfilter</b> Erstatter KA40027AA  H: 45 mm U: 93 mm I : 73/35 mm		<b>SN21588 Fuelfilter</b> Erstatter mm409870  H: 46 mm U: 35 mm I : 13/12/0 mm		<b>SA12022 Luftfilter</b> Erstatter 505315546  H: 52 mm U: 160 mm I : 110 mm	
<b>SA12287 Luftfilter</b> Erstatter 40074AA  H: 17 mm U: 127/118 mm I : 110/100 mm		<b>33661 Oliefilter</b> Erstatter MD097003  H: 82 mm U: 84/80 mm I : M 20 x 1.5		<b>SA12023 Luftfilter</b> Erstatter 505315571  H: 3 mm U: 255 mm I : 55 mm	
<b>AF 4066 Luftfilter</b>  H: 225 mm U: 110 mm I : 50/9 mm		<b>33726 Oliefilter</b> Erstatter MD135735/MD135737  H: 82 mm U: 72/68 mm I : M 20 x 1.5		<b>SA12024 Luftfilter</b> Erstatter 506076401  H: 61 mm U: 41 mm	
<b>5838 Fuelfilter</b> Erstatter mm408992  H: 35 mm U: 41 mm I : 25 mm		<b>PARTNER</b>		<b>SA12046 Luftfilter</b> Erstatter 315475  H: 18/15 mm U: 120 mm I : 72 mm	
<b>5856 Fuelfilter</b> Erstatter mm434147  H: 50 mm U: 35 mm I : 13/12/0 mm		<b>AF 1852 Luftfilter</b> Erstatter 315530  H: 64 mm U: 147 mm I : 106 mm  Forfilter er 10028		<b>SA12127 Luftfilter</b> Erstatter 506231801  H: 69 mm U: 151/105 mm I : 101/54/10 mm  Forfilter er SA22127	
<b>5844 Fuelfilter</b> Erstatter mm404879  H: 60 mm U: 29 mm I : 13/0 mm		<b>SA12020 Luftfilter</b> Erstatter 506224201  H: 54 mm U: 121/87 mm I : 75/41/11 mm  Forfilter er SA12021		<b>SA12247 Luftfilter</b> Erstatter 5062498/506249801  H: 65 mm U: 141/109 mm I : 95/63/0 mm	
<b>5819 Fuelfilter</b> Erstatter 91264-02200  H: 69 mm U: 35 mm I : 13/12/0 mm		<b>SA12021 Forfilter</b> Erstatter 506226301  H: 18 mm U: 195 mm I : 123/110/3 mm  Forfilter for SA12020		<b>SA12276 Luftfilter</b> Erstatter 5063671/506367101  H: 18 mm U: 200 mm I : 140 mm	

PARTNER	RANSOMES	ROBIN
<p><b>SA12285 Luftfilter</b> Erstatter 506347001</p> <p>H: 66 mm U: 154/106 mm l : 10 mm</p> 	<p><b>SA12099 Luftfilter</b> Erstatter 559286</p> <p>H: 35/30 mm U: 109 mm l : 100 mm</p> 	<p><b>SA12115 Luftfilter</b> Erstatter 580-30390-00</p> <p>H: 50/37 mm U: 84 mm l : 64 mm</p> 
<p><b>SA12365 Luftfilter</b> Erstatter 5063672F/5063672K</p> <p>H: 36 mm U: 126 mm l : 115 mm</p> 	<b>ROBIN</b>	
<p><b>SA12989 Luftfilter</b></p> <p>H: 80 mm U: 53/50 mm l : 30/5 mm</p> <p>Forfilter er SA12990</p> 	<p><b>SA12014 Luftfilter</b> Erstatter 210-32610-08</p> <p>H: 110/104 mm U: 111/67 mm l : 80/12 mm</p> 	<p><b>SA12116 Luftfilter</b> Erstatter 234-32604-07</p> <p>H: 85/83 mm U: 118/67 mm l : 70/0 mm</p> 
<p><b>SA12069 Luftfilter</b></p> <p>H: 161 mm U: 99 mm l : 52/7 mm</p> 	<p><b>SA12015 Luftfilter</b> Erstatter 228-32600-08</p> <p>H: 70 mm U: 108 mm l : 40 mm</p> 	<p><b>SA12117 Luftfilter</b> Erstatter 107-32701-00</p> <p>H: 80/76 mm U: 87/51 mm l : 60/0 mm</p> 
<p><b>10028 Forfilter</b> Erstatter 505315567</p> <p>H: 6 mm U: 182 mm l : 54 mm</p> <p>Forfilter for AF1852</p> 	<p><b>SA12106 Luftfilter</b> Erstatter 128-32602-07</p> <p>H: 46/35 mm U: 62 mm l : 46 mm</p> 	<p><b>SA12119 Luftfilter</b> Erstatter 106-32702-08</p> <p>H: 82 mm U: 76/42 mm l : 55/0 mm</p> 
<p><b>SA22127 Forfilter</b></p> <p>H: 19 mm U: 266 mm l : 132 mm</p> <p>Forfilter for SA12127</p> 	<p><b>SA12108 Luftfilter</b></p> <p>H: 155 mm U: 100 mm l : 52/7 mm</p> 	<p><b>SA12121 Luftfilter</b> Erstatter 252-32601-07</p> <p>H: 46/31 mm U: 91 mm l : 67 mm</p> 
<p><b>SA22247 Luftfilter</b> Erstatter 506268601/999806</p> <p>H: 17 mm U: 200 mm l : 152 mm</p> 	<p><b>SA12114 Luftfilter</b> Erstatter 228-32801-07</p> <p>H: 47 mm U: 185 mm l : 115 mm</p> 	<p><b>SA12125 Luftfilter</b> Erstatter 161-32612-08</p> <p>H: 24 mm U: 178 mm l : 111 mm</p> <p>Forfilter er SA22125</p> 
<p><b>SA23127 Luftfilter</b> Erstatter 506268701/999807</p> <p>H: 20 mm U: 257 mm l : 165 mm</p> 	<p><b>SA12141 Luftfilter</b> Erstatter 267-35003-01</p> <p>H: 68 mm U: 148/93 mm l : 89/44/10 mm</p> 	

ROBIN		ROBIN		ROBIN	
<b>SA12177 Luftfilter</b> Erstatte 262-32601-01  H: 55 mm U: 147/77 mm I : 103/34/7 mm		<b>SA12162 Luftfilter</b> Erstatte 227-32610-07  H: 63/60 mm U: 108/67 mm I : 55/0 mm		<b>SA12255 Luftfilter</b> Erstatte 541-35009-00  H: 25 mm U: 55 mm I : 37 mm	
<b>SA12148 Luftfilter</b> Erstatte 251-32831-12  H: 46/36 mm U: 217 mm I : 128 mm		<b>SA12166 Luftfilter</b> Erstatte 106-32704-07  H: 55/45 mm U: 61 mm I : 47 mm		<b>SA12260 Luftfilter</b> Erstatte 236-32601-07  H: 24 mm U: 121 mm I : 83 mm	
<b>SA12152 Luftfilter</b> Erstatte 227-36002-03  H: 30 mm U: 118 mm I : 82 mm		<b>SA12167 Luftfilter</b> Erstatte 228-32601-18  H: 24 mm U: 90 mm		<b>SA12270 Luftfilter</b> Erstatte 282-32601-07/282-32601-08  H: 27 mm U: 140 mm I : 87 mm	
<b>SA12153 Luftfilter</b> Erstatte 234-36002-03  H: 35 mm U: 138 mm I : 92 mm		<b>SA12171 Luftfilter</b> Erstatte 258-33319-05  H: 58 mm U: 85/52 mm I : 46/0 mm		<b>SA12275 Luftfilter</b> Erstatte 267-32602-18  H: 43 mm U: 168 mm I : 106 mm	
<b>SA12154 Luftfilter</b> Erstatte 243-32611-08  H: 21 mm U: 112 mm I : 61 mm		<b>SA12177 Luftfilter</b> Erstatte 231-32601-07/262-32601-07  H: 76 mm U: 147/77 mm I : 103/34/7 mm		<b>SA12278 Luftfilter</b> Erstatte 274-32603-07  H: 54 mm U: 100 mm I : 65 mm	
<b>SA12160 Luftfilter</b> Erstatte 226-32610-07  H: 58/54 mm U: 97/52 mm I : 52/0 mm		<b>SA12178 Luftfilter</b> Erstatte 252-32611-08  H: 20 mm U: 47 mm I : 29 mm		<b>SA12316 Luftfilter</b> Erstatte 520-30040-10  H: 6 mm U: 85 mm I : 16 mm	
<b>SA12161 Luftfilter</b> Erstatte 207-32606-18  H: 87/83 mm U: 106/67 mm I : 72/0 mm		<b>SA12252 Luftfilter</b>   H: 21 mm U: 55 mm I : 39 mm		<b>SA12326 Luftfilter</b> Erstatte 243-32600-08  H: 52 mm U: 100 mm I : 70/6 mm	

ROBIN		ROBIN		ROBIN	
<b>SA12339 Luftfilter</b> Erstatter 279-32606-08/279-32607-07  H: 71 mm U: 145/85 mm I : 98/37/6 mm 	<b>SA12415 Luftfilter</b> Erstatter 207-32600-08  H: 64/58 mm U: 121/96 mm I : 77/0 mm 	<b>5839 Fuelfilter</b> Erstatter 228-62110-08  H: 50 mm U: 35 mm I : 13/12/0 mm 			
<b>SA12340 Luftfilter</b> Erstatter 279-32603-08  H: 40 mm U: 138 mm I : 110 mm 	<b>SA12607 Luftfilter</b> Erstatter 246-32601-07  H: 48 mm U: 184/77 mm I : 147/41/7 (x2) mm 	<b>SN24632 Fuelfilter</b> Erstatter 243/62101-10  H: 104 mm U: 59/49 mm I : 7 (x2)/5 mm 			
<b>SA12410 Luftfilter</b> Erstatter 227-32803-17/227-73280-07  H: 59 mm U: 90/72 mm I : 33/9 mm 	<b>SA12620 Luftfilter</b> Erstatter 209-32620-07  H: 93/86 mm U: 111/84 mm I : 80/0 mm 	<b>SO 6086 Oliefilter</b> Erstatter 248-65801-00  H: 62 mm U: 69/65 mm I : 3/4 - 16 UNF 			
<b>SA12411 Luftfilter</b> Erstatter 235-34701-21  H: 67 mm U: 226/70 mm I : 194/39/7 (x2) mm 	<b>SA12708 Luftfilter</b> Erstatter 209-32607-08  H: 74/68 mm U: 133/110 mm I : 81/0 mm 	<b>SO64301 Oliefilter</b> Erstatter 228-64301-00  H: 64 mm U: 30 mm I : 13/12/0 mm 			
<b>SA12412 Luftfilter</b> Erstatter 157-36201-01  H: 60/48 mm U: 79 mm I : 57 mm Forfilter er SA22412 	<b>SA22177 Forfilter</b>  H: 9 mm U: 190 mm I : 72 mm Forfilter for SA12177 	<b>SO64302 Oliefilter</b> Erstatter 243-64301-00  H: 96 mm U: 20 mm I : 12 mm 			
<b>SA12413 Luftfilter</b> Erstatter 220-32812-04  H: 46 mm U: 124/60 mm I : 86/22/7 mm 	<b>SA22410 Forfilter</b> Erstatter 227-32613-08  H: 9 mm U: 122 mm I : 53 mm Forfilter for SA12410 	<b>SO64303 Oliefilter</b> Erstatter 251-64302-01  H: 67 mm U: 31 mm I : 13/12/0 mm 			
<b>SA12414 Luftfilter</b> Erstatter 206-32601-07  H: 62/57 mm U: 87/67 mm I : 60/0 mm 	<b>SA22412 Forfilter</b> Erstatter 157-36210-08  H: 4 mm U: 117 mm I : 52 mm Forfilter for SA12412 	<div style="background-color: red; color: white; text-align: center; padding: 2px;"><b>RUGGERINI</b></div> <b>SA12096 Luftfilter</b> Erstatter 175.50  H: 49 mm U: 126 mm I : 76 mm 			

RUGGERINI		RUGGERINI		RUGGERINI	
<b>SA12315 Luftfilter</b> Erstatte 2175.2390/2175.2520 H: 72/65 mm U: 125 mm I : 65/10 mm Forfilter er SA22304		<b>FF 230 Fuelfilter</b> Erstatte 175-04 H: 64 mm U: 63 mm I : 13 mm		<b>LF 655 Oliefilter</b> Erstatte 175.22 H: 120 mm U: 80 mm I : 3/4 - 16 UNF	
<b>SA17096 Luftfilter</b> Erstatte 175.40/175.43 H: 38 mm U: 160 mm I : 157 mm		<b>SN 296 Fuelfilter</b> Erstatte 175.08 H: 80 mm U: 63 mm I : 16/13 mm		<b>31002 Oliefilter</b> Erstatte 175-11 H: 117 mm U: 51 mm I : M 14 x 1.5	
<b>SA22304 Forfilter</b> H: 5 mm U: 200 mm I : 60 mm Forfilter for SA12315		<b>FF 5091 Fuelfilter</b> Erstatte 175.23 H: 56 mm U: 80 mm I : M 16 x 1.5		<b>30228 Oliefilter</b> Erstatte 175-05 H: 65 mm U: 23 mm I : 10 mm/By-pass	
<b>SA 7027 Luftfilter</b> Erstatte 175-47 H: 37 mm U: 149 mm I : 72 mm		<b>FF42002 Fuelfilter</b> Erstatte 175.19 H: 78 mm U: 77 mm I : M 16 x 1.5		<b>SO 8035 Oliefilter</b> H: 82 mm U: 70 mm I : 14 mm	
<b>FF 146 Fuelfilter</b> Erstatte D952446 H: 114 mm U: 65 mm I : 13 mm		<b>KX 15 Fuelfilter</b> H: 63 mm U: 51 mm I : 13 mm		<b>SO 8077 Oliefilter</b> Erstatte CD102830/175.07 H: 113 mm U: 69 mm I : 13 mm	
<b>FF 5091 Fuelfilter</b> Erstatte 175-28 H: 58 mm U: 78 mm I : M 16 x 1.5		<b>SN80029 Fuelfilter</b> H: 87 mm U: 54/48 mm I : 7/7/6 mm		<b>SACHS</b>	
<b>SN21565 Fuelfilter</b> Erstatte 175.32 H: 71 mm U: 51 mm I : 13 mm		<b>LF 3826 Oliefilter</b> Erstatte 175.24 H: 59 mm U: 77/75 mm I : 3/4 - 16 UNF		<b>BE 4010 Fuelfilter</b> Erstatte 963601250 H: 45 mm U: 21 mm I : 4 mm	
<b>10018 Luftfilter</b> Erstatte 0925111000 H: 55 mm U: 105 mm I : 80 mm					

SACHS	SACHS	SLANZI
<b>SA11110 Luftfilter</b> Erstatte 001173020/001173030 H: 76/69 mm U: 59/53 mm I : 52/8 mm Inderfilter for AF4525 	<b>SA22025 Luftfilter</b> H: 10 mm U: 112 mm I : 56 mm Forfilter for SA12025 	<b>SN80005 Fuelfilter</b> Erstatte 40.60.01 H: 57 mm U: 50 mm I : 14/6 mm 
<b>AF 4525 Luftfilter</b> H: 71 mm U: 98 mm I : 60 mm Inderfilter er SA11110 	<b>SLANZI</b>	
	<b>SA17352 Luftfilter</b> Erstatte 40.84.07 H: 210 mm U: 133 mm I : 85/0 mm 	<b>LF 655 Oliefilter</b> Erstatte 40.10.53 H: 120 mm U: 80 mm I : 3/4 - 16 UNF 
<b>SA12025 Luftfilter</b> Erstatte 2625010000 H: 67 mm U: 71 mm I : 38/0 mm Forfilter er SA22025 	<b>SA18011 Luftfilter</b> Erstatte 40.84.10 H: 193 mm U: 81 mm I : 54/8 mm 	<b>LF 3678 Oliefilter</b> Erstatte 40.70.37 H: 73 mm U: 79/76 mm I : M 14 x 1.5 By-pass 
<b>SA12029 Luftfilter</b> Erstatte 122173030 H: 15 mm U: 86 mm I : 86 mm 	<b>SA 7000 Luftfilter</b> Erstatte 40.84.05 H: 207 mm U: 90 mm I : 50 mm 	<b>31002 Oliefilter</b> Erstatte 40.70.45 H: 117 mm U: 51 mm I : M 14 x 1.5 
<b>SA12030 Luftfilter</b> Erstatte 119173030 H: 6 mm U: 105 mm I : 95 mm 	<b>FF 146 Fuelfilter</b> Erstatte 40.60.03 H: 80 mm U: 63 mm I : 16/13 mm 	<b>SO 8002 Oliefilter</b> Erstatte 40.70.05 H: 61 mm U: 70 mm I : 14 mm 
<b>SA12031 Luftfilter</b> Erstatte 114173531 H: 20 mm U: 103 mm I : 55 mm 	<b>SN 535 Fuelfilter</b> Erstatte 40.60.40 H: 117 mm U: 51/48 mm I : M 12 x 1.75 	<b>SO 8077 Oliefilter</b> Erstatte 40.70.06 H: 113 mm U: 69 mm I : 13 mm 
<b>SA12032 Luftfilter</b> Erstatte 123173110 H: 21 mm U: 96 mm I : 88 mm 	<b>FF42002 Fuelfilter</b> Erstatte 40.60.37 H: 78 mm U: 77 mm I : M 16 x 1.5 	<b>SO 8834 Oliefilter</b> Erstatte 40.70.38 H: 184 mm U: 70 mm I : 30/15 mm 

STIHL		STIHL		STIHL	
<b>BE 4004 Fuelfilter</b> Erstatte 1110-358-1800  H: 30 mm U: 20 mm		<b>SA11115 Luftfilter</b> Erstatte 4201-140-1802  H: 57 mm U: 66/52 mm I : 47/12 mm  Inderfilter for AF 4525		<b>SA12216 Luftfilter</b> Erstatte 4203-141-0300  H: 40 mm U: 74 mm I : 45/0 mm  Forfilter er SA22216	
<b>BE 4005 Fuelfilter</b> Erstatte 1115-350-3503  H: 45 mm U: 19 mm I : 7 mm		<b>SA12128 Luftfilter</b> Erstatte 4135-124-2800  H: 7 mm U: 70 mm I : 62 mm  Forfilter er SA22128		<b>SA12219 Luftfilter</b> Erstatte 4223-140-1800  H: 29 mm U: 117 mm I : 69 mm	
<b>BE 4022 Fuelfilter</b> Erstatte 4112-350-3500		<b>SA12210 Luftfilter</b> Erstatte 4134-141-0300  H: 25 mm U: 86 mm I : 72 mm		<b>SA12227 Luftfilter</b> Erstatte 1121-120-1615/1121-121-7001  H: 33/26 mm U: 78 mm I : 56/54 mm	
<b>BE 4024 Fuelfilter</b> Erstatte 0000-350-3502  H: 45 mm U: 18 mm I : 5 mm		<b>SA12212 Luftfilter</b> Erstatte 4223-141-0300  H: 46 mm U: 137 mm I : 89 mm  Forfilter er SA22212		<b>SA12228 Luftfilter</b> Erstatte 1110-120-1601  H: 15 mm U: 109 mm I : 104 mm	
<b>AF 4525 Luftfilter</b> Erstatte 4201-141-0300  H: 71 mm U: 98 mm I : 60 mm  Inderfilter er SA11110/SA11113/SA11115		<b>SA12213 Luftfilter</b> Erstatte 4221-141-0300  H: 58 mm U: 112 mm I : 53/7 mm  Forfilter er SA12215		<b>SA12229 Luftfilter</b> Erstatte 1118-120-1610  H: 24 mm U: 93 mm I : 66 mm	
<b>SA11113 Luftfilter</b> Erstatte 4201-140-1801  H: 65 mm U: 63/40 mm I : 37 mm  Inderfilter for AF 4525		<b>SA12214 Luftfilter</b> Erstatte 4221-140-1800  H: 43 mm U: 48 mm I : 44/27 mm  Inderfilter for SA12213		<b>SA12230 Luftfilter</b> Erstatte 1108-120-1600  H: 51 mm U: 56 mm I : 50 mm	
<b>SA11114 Luftfilter</b> Erstatte 4201-141-0310  H: 3 mm U: 154/71 mm  Forfilter for AF 4525		<b>SA12215 Forfilter</b> Erstatte 4221-141-0310  H: 3 mm U: 168 mm I : 51 mm  Forfilter for SA12213		<b>SA12231 Luftfilter</b> Erstatte 1125-120-1620  H: 32 mm U: 84 mm I : 75 mm	



















STIHL		STIHL		STIHL	
<b>SA12232 Luftfilter</b> Erstatte 1115-120-1615  H: 30/24 mm U: 95/88 mm l : 87 mm		<b>SA12241 Luftfilter</b> Erstatte 1113-120-1603  H: 46/28 mm U: 81 mm l : 67 mm		<b>SA12290 Luftfilter</b> Erstatte 1121-120-1617  H: 43 mm U: 89 mm l : 79 mm	
<b>SA12234 Luftfilter</b> Erstatte 1111-120-1601  H: 20 mm U: 130 mm l : 103 mm		<b>SA12250 Luftfilter</b> Erstatte 4203-141-0301 A  H: 35 mm U: 128 mm l : 87 mm		<b>SA12293 Luftfilter</b> Erstatte 4282-141-0300  H: 35 mm U: 203 mm l : 81 mm	
<b>SA12363 Luftfilter</b> Erstatte 1122-120-1620  H: 38 mm U: 130 mm l : 124 mm		<b>SA12261 Luftfilter</b> Erstatte 4123-124-0801  H: 6 mm U: 61 mm l : 50 mm		<b>SA12294 Luftfilter</b> Erstatte 4119-120-1606  H: 15/10 mm U: 118 mm l : 92 mm	
<b>SA12237 Luftfilter</b> Erstatte 4114-124-0800  H: 8 mm U: 55 mm		<b>SA12262 Luftfilter</b> Erstatte 4126-124-0800  H: 3 mm U: 68 mm l : 59 mm		<b>SA12350 Luftfilter</b> Erstatte 4224-141-0300A  H: 47 mm U: 140 mm l : 103 mm	
<b>SA12238 Luftfilter</b> Erstatte 4210-141-0302  H: 28 mm U: 60 mm l : 58 mm		<b>SA12263 Luftfilter</b> Erstatte 4126-124-0801  H: 8 mm U: 73 mm l : 58 mm		<b>SA12352 Luftfilter</b> Erstatte 1125-120-1622  H: 30/12 mm U: 105 mm l : 90/80 mm	
<b>SA12239 Luftfilter</b> Erstatte 1119-120-1611  H: 28 mm U: 104 mm l : 80 mm		<b>SA12265 Luftfilter</b> Erstatte 0000-120-1605A/0000-141-0300A  H: 4 mm U: 143 mm l : 35 mm		<b>SA12367 Luftfilter</b> Erstatte 4119-141-0300  H: 3 mm U: 115 mm l : 88 mm	
<b>SA12240 Luftfilter</b> Erstatte 4112-124-0801  H: 8 mm U: 51 mm		<b>SA12271 Luftfilter</b> Erstatte 4123-124-0800  H: 4 mm U: 62 mm l : 48 mm		<b>SA22128 Forfilter</b> Erstatte 4135-124-1500  H: 6 mm U: 70 mm l : 60 mm  Forfilter for SA12128	

STIHL		TORO		TORO	
<b>SA22212 Forfilter</b> Erstatte 4223-141-0600 H: 18 mm U: 125 mm l : 77 mm Forfilter for SA12212		<b>SA10793 Luftfilter</b> Erstatte 235116 H: 51 mm U: 151 mm l : 118 mm Forfilter er SA20793		<b>5838 Fuelfilter</b> Erstatte 432550 H: 35 mm U: 41 mm l : 25 mm	
<b>SA22216 Forfilter</b> Erstatte 4203-141-0310 H: 3 mm U: 121 mm l : 37 mm Forfilter for SA12216		<b>SA11932 Luftfilter</b> Erstatte 4508302 H: 76 mm U: 152 mm l : 118 mm		<b>SN20002 Fuelfilter</b> Erstatte 0406925-11 H: 69 mm U: 35 mm l : 7/7 mm	
<b>SA22294 Forfilter</b> Erstatte 4119-141-1700 H: 10 mm U: 115 mm l : 88 mm Forfilter for SA12294		<b>SA12039 Luftfilter</b> Erstatte 463960 H: 17 mm U: 67 mm l : 64 mm		<b>SN20105 Fuelfilter</b> Erstatte 425240/125 my H: 45 mm U: 34 mm l : 7/7 mm	
<b>SA22350 Luftfilter</b> Erstatte 4224-140-1801A H: 25/8 mm U: 120 mm l : 84 mm		<b>SA12089 Luftfilter</b> Erstatte 820660 H: 102 mm U: 206 mm l : 165 mm		<b>53026 Fuelfilter</b> Erstatte 637650/638300 H: 82 mm U: 78 mm l : M 16 x 1.5	
<b>TORO</b>		<b>SA12186 Luftfilter</b> Erstatte 777950 H: 28/10 mm U: 138/125 mm l : 118/106 mm		<b>LF 3682 Oliefilter</b> Erstatte 987431 H: 130 mm U: 98 mm l : 3/4 - 16 UNF	
<b>SA10016 Luftfilter</b> Erstatte 814120 H: 30 mm U: 175 mm l : 49 mm		<b>SA12242 Luftfilter</b> Erstatte 545190 H: 10 mm U: 58 mm l : 9 mm (x2)		<b>LF 3646 Oliefilter</b> Erstatte 998384 H: 76 mm U: 84 mm l : M 20 x 1.5	
<b>SA10018 Luftfilter</b> Erstatte 810100 H: 27 mm U: 168 mm l : 93 mm		<b>SA12471 Luftfilter</b> Erstatte 623970 H: 60 mm U: 129/61 mm l : 92/26 mm		<b>33726 Oliefilter</b> Erstatte 674330 H: 82 mm U: 72 mm l : M 20 x 1.5	
<b>SA10019 Luftfilter</b> Erstatte 639380 H: 28/7 mm U: 165/153 mm l : 88/75 mm					

WACKER		WACKER		WACKER	
<b>BE 4010 Fuelfilter</b> Erstatter 0108058  H: 45 mm U: 21 mm I : 4 mm		<b>SA11114 Luftfilter</b> Erstatter 58382  H: 3 mm U: 154/71 mm  Forfilter for AF 4525		<b>SA12162 Luftfilter</b> Erstatter 54798  H: 63/60 mm U: 108/67 mm I : 55/0 mm	
<b>52003 Fuelfilter</b> Erstatter 15206  H: 108 mm U: 35 mm I : 6/8 mm		<b>SA11120 Luftfilter</b> Erstatter 77020  H: 22 mm U: 131 mm I : 112 mm  Forfilter er SA11122		<b>SA12334 Luftfilter</b> Erstatter 0157193  H: 55/16 mm U: 170 mm I : 55 mm  Forfilter er SA22334	
<b>AF25376 Luftfilter</b> Erstatter 95091  H: 95 mm U: 164 mm I : 87 mm		<b>SA11122 Forfilter</b>  H: 10 mm U: 128 mm I : 107 mm  Forfilter for SA11120		<b>SA12338 Luftfilter</b> Erstatter 0204305/204305  H: 17 mm U: 195 mm I : 127 mm	
<b>1396 Luftfilter</b> Erstatter 80856  H: 42 mm U: 273/172 mm I : 25/8 mm		<b>SA12106 Luftfilter</b> Erstatter 66767  H: 46/35 mm U: 62 mm I : 46 mm		<b>SA12402 Luftfilter</b> Erstatter 77194  H: 25 mm U: 95 mm I : 78 mm	
<b>SA10091 Luftfilter</b> Erstatter 14819  H: 80 mm U: 78 mm I : 59 mm		<b>SA12126 Luftfilter</b> Erstatter 0108076  H: 58 mm U: 107 mm I : 82 mm  Forfilter er 10017		<b>SA12821 Luftfilter</b> Erstatter 71622  H: 68 mm U: 101/73 mm I : 34/32/5 mm  Forfilter er SA22821	
<b>SA11110 Luftfilter</b> Erstatter 0094693  H: 76/69 mm U: 59/53 mm I : 52/8 mm  Inderfilter for AF 4525		<b>AF25351 Luftfilter</b> Erstatter 66108  H: 173 mm U: 126 mm I : 65/9 mm		<b>SA12822 Luftfilter</b> Erstatter 72314  H: 52 mm U: 101/73 mm I : 34/32/5 mm  Forfilter er SA22309	
<b>AF 4525 Luftfilter</b> Erstatter 33704  H: 71 mm U: 98 mm I : 60 mm  Inderfilter er SA11110		<b>1394 Luftfilter</b> Erstatter 97711/0095711  H: 30 mm U: 124/68 mm I : 102/45 mm		<b>AF25433 Luftfilter</b> Erstatter 66588  H: 135 mm U: 105/97 mm I : 35/0 mm	











WACKER		WACKER		YAMAHA	
<b>SA1987 Luftfilter</b> Erstatter 95254  H: 79 mm U: 147/92 mm I : 107/52 mm Forfilter er SA22157	<b>SN21593 Fuelfilter</b> Erstatter 95950  H: 130/103 mm U: 40 mm I : 8 mm	<b>SA12085 Luftfilter</b> Erstatter JA4-14450-00  H: 29/22 mm U: 164 mm I : 89 mm Forfilter er SA22085			
<b>SA22125 Forfilter</b>  H: 15 mm U: 185 mm I : 114 mm Forfilter for SA22125	<b>59905 Fuelfilter</b> Erstatter M36265/0112179  H: 72 mm U: 25 mm I : 14 mm	<b>SA12105 Luftfilter</b> Erstatter J10-14450-00/J10-14450-10  H: 146 mm U: 146/105 mm I : 28/0 mm			
<b>10017 Forfilter</b> Erstatter 0108074  H: 20 mm U: 138 mm I : 92 mm Forfilter for SA12126	<b>33378 Oliefilter</b> Erstatter 94930  H: 64 mm U: 42 mm I : 14 mm By-Pass	<b>SA12146 Luftfilter</b> Erstatter JN6-E4450-00  H: 40 mm U: 320/158 mm I : 255/158 mm			
<b>SA22129 Forfilter</b> Erstatter 95294  H: 8 mm U: 176 mm I : 65 mm Forfilter for SA11129	<b>YAMAHA</b>		<b>SA12198 Luftfilter</b>  H: 7 mm U: 88 mm I : 16 mm		
<b>SA22309 Forfilter</b> Erstatter 76941  H: 6 mm U: 114 mm I : 44 mm Forfilter for SA12822	<b>5571 Fuelfilter</b> Erstatter 646-24251-02/717635  H: 60 mm U: 19 mm I : 5/5 mm	<b>SA22005 Forfilter</b> Erstatter J10-14417-00  H: 11 mm U: 170 mm I : 138 mm Forfilter for SA12005			
<b>SA22334 Forfilter</b> Erstatter 016459  H: 8 mm U: 116 mm I : 85 mm Forfilter for SA12334	<b>SA12005 Luftfilter</b> Erstatter J38-14450-00  H: 148 mm U: 105 mm I : 33/32/0 mm Forfilter er SA22005	<b>SA22083 Forfilter</b> Erstatter JA9-14417-00  H: 5 mm U: 134 mm I : 102 mm Forfilter for SA12083			
<b>FF 149 Fuelfilter</b> Erstatter 49223  H: 101 mm U: 49/44 mm I : 8/8 mm	<b>SA12083 Luftfilter</b> Erstatter JA9-14450-00  H: 20/13 mm U: 197 mm I : 108 mm Forfilter er SA22083	<b>SA22085 Forfilter</b> Erstatter JA4-14417-00  H: 5 mm U: 133 mm I : 70 mm Forfilter for SA12085			

YAMAHA		YANMAR		YANMAR	
<b>5839 Fuelfilter</b> Erstatte YA2-228621-10-08  H: 50 mm U: 35 mm I : 13/12/0 mm		<b>AF25607 Luftfilter</b> Erstatte 114250-12540  H: 46 mm U: 105/100 mm I : 52/6 mm  Forfilter er SA22822		<b>FF 5103 Fuelfilter</b> Erstatte 129100-55650  H: 88 mm U: 50 mm I : 20/0 mm	
<b>SN21602 Fuelfilter</b> Erstatte 1FK-24450-00  H: 99 mm U: 37 mm I : 8/8 mm		<b>SA12157 Luftfilter</b> Erstatte 114650-12540  H: 73 mm U: 143/99 mm I : 94/51/6 mm		<b>5852 Fuelfilter</b> Erstatte 58781-01780  H: 46 mm U: 42 mm I : 14 mm	
<b>SO64301 Oliefilter</b> Erstatte YA2-28643-01-00/575423-8  H: 64 mm U: 30 mm I : 13/12/0 mm		<b>10153 Luftfilter</b> Erstatte 114210-12590  H: 78/71 mm U: 130/110 mm I : 73/55/7 mm		<b>5856 Fuelfilter</b> Erstatte 171081-55910  H: 50 mm U: 35 mm I : 13/12/0 mm	
<b>YANMAR</b>		<b>10069 Luftfilter</b> Erstatte 118400-12520  H: 65 mm U: 220/87 mm I : 180/45 mm		<b>FF 5468 Fuelfilter</b> Erstatte 121850-55710  H: 69 mm U: 35 mm I : 13/12/0 mm	
<b>AF 437KM Luftfilter</b> Erstatte 121850-12510/171064-12540  H: 280 mm U: 159/134 mm I : 66/17 mm		<b>SA12094 Luftfilter</b> Erstatte 105370-12570  H: 98 mm U: 136/114 mm I : 42 mm		<b>SA12600 Luftfilter</b> Erstatte 128171-12540  H: 80 mm U: 98/53 mm I : 82/38 mm	
<b>SA12109 Luftfilter</b> Erstatte 160760-12530  H: 29 mm U: 115 mm I : 100 mm		<b>SA12094 Luftfilter</b> Erstatte 105370-12570  H: 98 mm U: 136/114 mm I : 42 mm		<b>5819 Fuelfilter</b> Erstatte 104500-55710  H: 69 mm U: 35 mm I : 13/12/0 mm	
<b>SA12109 Luftfilter</b> Erstatte 160760-12530  H: 29 mm U: 115 mm I : 100 mm		<b>AF 4066 Luftfilter</b>  H: 225 mm U: 110 mm I : 50/9 mm		<b>5827 Fuelfilter</b> Erstatte 124550-55700  H: 90 mm U: 35 mm I : 13/12/0 mm	
<b>SA12156 Luftfilter</b> Erstatte 114650-12590  H: 73 mm U: 142/99 mm I : 94/50/9 mm		<b>AF 4502K Luftfilter</b> Erstatte 119860-12510  H: 188/174 mm U: 124/107 mm I : 44/12 mm		<b>SN21593 Fuelfilter</b> Erstatte 114250-55120  H: 130/103 mm U: 40 mm I : 8 mm	

YANMAR		YANMAR		SLANGEFILTRE	
<b>SN21594 Fuelfilter</b> Erstatte 114350-55120  H: 155/130 mm U: 40 mm I : 8/2 mm	<b>59902 Fuelfilter</b> Erstatte 119802-55710/119802-55710T  H 118/60 mm U: 53/20 mm I : 20/16 mm	<b>5563 Slangefilter</b>  H: 104 mm U: 37 mm I : 6/8 mm			
<b>SN21595 Fuelfilter</b> Erstatte 114650-55120  H: 198/171 mm U: 40 mm I : 8/2 mm	<b>FF42003 Fuelfilter</b> Erstatte CN039623/121850-55701  H: 71 mm U: 78 mm I : M 20 x 1.5	<b>52006 Slangefilter</b>  H: 121 mm U: 50 mm I : 6/8 mm			
<b>SN21596 Fuelfilter</b> Erstatte 114652-55300  H: 229/201 mm U: 40 mm I : 8/2 mm	<b>LF 3646 Oliefilter</b> Erstatte 129150-35151/129150-35152  H: 76 mm U: 84 mm I : M 20 x 1.5	<b>52007 Slangefilter</b>  H: 200 mm U: 50 mm I : 6/8 mm			
<b>5862 Fuelfilter</b> Erstatte 114260-55120  H: 180/154 mm U: 40 mm I : 8/2 mm	<b>LF 3536 Oliefilter</b> Erstatte 119005-35100/124550-35110/171056-35110  H: 102 mm U: 84 mm I : M 20 x 1.5	<b>NF2455 Slangefilter</b>  H: 130 mm U: 70 mm I : 7 mm			
<b>FF 230 Fuelfilter</b> Erstatte 120324-55760  H: 61 mm U: 73 mm I : 13 mm	<b>33699 Oliefilter</b> Erstatte 114250-35100/114250-35110  H: 97/87 mm U: 24/15 mm I : 7/0 mm	<b>WK31/5 Slangefilter</b>  H: 106 mm U: 38 mm I : 8 mm			
<b>52002 Fuelfilter</b> Erstatte 129052-55630  H: 76 mm U: 52/44 mm I : 8/8 mm	<div style="background-color: red; color: white; text-align: center; padding: 2px;"><b>SLANGEFILTRE</b></div> <b>NF2251 Slangefilter</b>  H: 80 mm U: 49 mm I:	<b>5565 Slangefilter</b>  H: U: I : 10 mm			
<b>SN21603 Fuelfilter</b> Erstatte 105370-55710  H: 86 mm U: 30 mm I : 11/8/0 mm	<b>SN20002 Slangefilter</b>  H: 67 mm U: 30 mm I : 7 mm	<b>5554 Slangefilter</b>  H: 117 mm U: 54 mm I : 6/8 mm			

**SLANGEFILTERE**

**SLANGEFILTERE**

<p><b>FF 5077 Slangefilter</b></p>  <p>H: 91 mm U: 48 mm I : 5/8 - 24 mm (Gevind)</p>	<p><b>5557 Slangefilter</b></p>  <p>H: 86 mm U: 48/42 mm I:</p>	
<p><b>FF 5079 Slangefilter</b></p>  <p>H: 97 mm U: 48 mm I : 10 mm</p>	<p><b>5842 Slangefilter</b></p>  <p>H: 97 mm U: 55/45 mm I : 7/8 mm</p>	
<p><b>FF 149 Slangefilter</b></p>  <p>H: 97 mm U: 48 mm I : 8 mm</p>	<p><b>5842-U Slangefilter</b></p>  <p>H: 97 mm U: 55/45 mm I : 7/8 mm</p>	
<p><b>5571 Slangefilter</b></p>  <p>H: 57 mm U: 19 mm I : 5 mm</p>		
<p><b>52003 Slangefilter</b></p>  <p>H: 97 mm U: 48 mm I : 6/8 mm</p>		
<p><b>SN24632 Slangefilter</b></p>  <p>H: 96 mm U: 50/40 mm I : 6 mm</p>		
<p><b>SN25000 Slangefilter</b></p>  <p>H: U: I:</p>		





## **Filtertechnik A/S**

Filtertechnik A/S  
Korskildeeng 2  
DK-2670 Greve  
Tlf. +45 5613 1072 . Fax +45 5613 1073  
[www.filtertechnik.dk](http://www.filtertechnik.dk)



## **Filtertechnik Sverige**

Filtertechnik Sverige AB  
652 21 Karlstad  
Tlf. +46 (0)54 690900 . Fax +46 (0)54 690909  
[www.filtertechnik.se](http://www.filtertechnik.se)



## **Lekang Maskin AS**

1550 Hølen, Norge  
Tlf. +47 6498 2000 . Faks +47 6498 2002  
[www.lekang.com](http://www.lekang.com)

Forhandler: